



# Tripod Stand Stretch Cover

## User Instructions 121017

1. Position collapsed speaker stand in the intended performance position. The adjustment clamps and knobs used for stand operation should be positioned toward the rear of the stand (opposite the sides to be covered). The vertical center tube should be on its lowest height setting.
2. Identify parts of the Stretch Cover:
  - a) Identify the top corner of the stretch cover by locating the cinch strap with D-ring.
  - b) Identify the bottom corners of the stretch cover by locating the sewn-in foot pockets.
  - c) The side with visible stitching will face in toward the tripod stand.
3. With the speaker stand in position, open the tripod base to provide a stable footprint.
4. Begin installation of the cover by placing the integrated foot pockets over the tripod feet.
5. Next, position the top corner of the stretch cover against the lowered center tube. Leaving at least 3" - 4" of tube exposed above the top of the cinch strap is a good rule of thumb, so that installation of the speaker socket and other attachments is not affected by the cover.
6. Wrap the cinch strap around the center tube, looping around the back of the tube so the grippy rubber side is in full contact. The loose end of the strap should go thru the D-Ring and then wrap back onto itself; secure the end by pressing the hook & loop Velcro together.
7. Before raising the center tube, install the speaker and other attachments onto stand as normal.
8. Raise stand to desired height. The stretch cover will automatically stretch to size, creating a tight fit on the stand.



*Open Tripod Base*



*Place Feet in Pockets*



*Continue Around Tripod*



*Secure Bottom of Cover in Place*



*Place Cinch Strap 3 - 4" from Top*



*Wrap Cinch Strap Thru D-Ring*



*Secure Velcro*



*Raise Center Tube*