



Colour Burst LED flower effect



Musikhaus Thomann

Thomann GmbH

Hans-Thomann-Straße 1

96138 Burgebrach

Germany

Telephone: +49 (0) 9546 9223-0

E-mail: info@thomann.de

Internet: www.thomann.de

07.03.2018, ID: 415613

Table of contents

1 General information		
	1.1 Further information	. :
	1.2 Notational conventions	. (
	1.3 Symbols and signal words	. (
2	Safety instructions	. •
3	Features 1	
4	Installation	
5	Connections and operating elements	
6	Operating	
7	Technical specifications2	
8	Cleaning	2
9	Protecting the environment	2



1 General information

This manual contains important instructions for the safe operation of the unit. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the device. If you sell the unit please make sure that the buyer also receives this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change.



1.1 Further information

On our website (<u>www.thomann.de</u>) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.	
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.	
Online guides	Our online guides provide detailed information on technical basics and terms.	
Personal consultation	For personal consultation please contact our technical hotline.	
Service	If you have any problems with the device the customer service will gladly assist you.	



1.2 Notational conventions

This manual uses the following notational conventions:

Letterings

The letterings for connectors and controls are marked by square brackets and italics.

Examples: [VOLUME] control, [Mono] button.

1.3 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.



Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
WARNING!	This combination of symbol and signal word indicates a possible dangerous situation that can result in death or serious injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
A	Warning – high-voltage.
	Warning – suspended load.



Warning signs	Type of danger
<u>^</u>	Warning – danger zone.



2 Safety instructions

Intended use

This device is intended to be used as an electronic illumination effect using LED technics. The device is designed for professional use and is not suitable for use in households. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.



Safety



DANGER!

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.



DANGER!

Electric shock caused by high voltages inside

Within the device there are areas where high voltages may be present. Never remove any covers.

There are no user-serviceable parts inside.

Do not use the device if covers, protectors or optical components are missing or damaged.





WARNING!

Eye damage caused by high light intensity

Never look directly into the light source.



WARNING!

Risk of epileptic shock

Strobe lighting can trigger seizures in photosensitive epilepsy. Sensitive persons should avoid looking at strobe lights.



NOTICE!

Risk of fire

Do not block areas of ventilation. Do not install the device near any direct heat source. Keep the device away from naked flames.





NOTICE!

Operating conditions

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.



NOTICE!

External power supply

The device is powered by an external power supply. Before connecting the external power supply, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly the user.

Unplug the external power supply before electrical storms occur and when the device is unused for long periods of time to reduce the risk of electric shock or fire.



3 Features

Compact effect spotlight for large-area RGB dot rotation effects.

- \blacksquare 3 × 3 W LEDs (RGB)
- Control via supplied remote control
- Preprogrammed automatic shows
- Sound control
- 12 V power supply included



4 Installation

Unpack and carefully check that there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.



WARNING!

Risk of injury caused by falling objects

Make sure that the installation complies with the standards and rules that apply in your country. Always secure the device with a secondary safety attachment, such as a safety cable or a safety chain.





NOTICE!

Risk of overheating

Always ensure sufficient ventilation.

The ambient temperature must always be below 40 °C (104 °F).



NOTICE!

Use of stands



When mounting the device onto a stand, ensure that the stand is in a safe and stable position and that the weight of the device does not exceed the maximum permissible load capacity of the stand.





NOTICE!

Possible data transmission errors

For error-free operation make use of dedicated DMX cables and do not use ordinary microphone cables.

Never connect the DMX input or output to audio devices such as mixers or amplifiers.

Options

You can install the device in either the hanging or standing position. During use, the device must always be attached to a solid surface or to an approved support. Use the openings provided on the bracket for attaching.

Always work from a stable platform whenever installing, moving or servicing the unit. In doing so, the area underneath the device must be cordoned off.

The safety-rope must be attached to the bracket.






Please note that this device must not be connected to a dimmer.



5 Connections and operating elements





1	Mounting bracket.
2	Locking screws for the mounting bracket.
3	Sensor for the signals from the included remote control.
4	[MIC]
	Built-in microphone for sound-controlled operation.
5	[MICROPHONE SENSITIVITY]
	Control to adjust the sensitivity of the built-in microphone.
6	[12V=]
	Connection socket for the supplied 12 V power adapter.



6 Operating

The unit functions are only controlled by the included remote control. The unit is ready for use as soon as the supplied 12 V power supply is plugged into the unit and connected to a grounded mains socket.

To use the remote control, point its infrared diode at the infrared sensor on the unit and press the desired buttons.





Button labelling:	Function
[AUTO]	Enabling / disabling the automatic mode.
[MUSIC]	Enabling / disabling the sound-controlled mode.
[ON/OFF]	Blackout
[-]	Decreasing the flash speed of the stroboscope effect.
[11]	No function.
[+]	Increasing the flash speed of the stroboscope effect.
[A]	Enabling / disabling the stroboscope effect.
[B]	No function.
[C]	No function.
[1]	Selecting fixed colour red.
[2]	Selecting fixed colour bright green.
[3]	Selecting mixed colour green / blue.
[4]	Selecting mixed colour red / green.


Colour Burst




Button labelling:	Function
[5]	Selecting fixed colour blue.
[6]	Selecting mixed colour red / green / blue.
[7]	Selecting mixed colour red / blue.
[8]	Selecting mixed colour red / blue.
[9]	Selecting mixed colour red / green.
[0]	Selecting fixed colour dark green.
[-/], つ	No function.



7 Technical specifications





- 138 mm -

LED configuration:	3 × 3 W LEDs, RGB
Power supply	Power adapter (12 V, 1000 mA, positive pole via inner contact)
Power consumption	6 W
Dimensions (W \times H \times D)	146 mm × 160 mm × 138 mm
Weight	Approx. 1 kg

8 Cleaning

Optical lenses

Clean the optical lenses, that are accessible from the outside, regularly in order to optimize the light output. The frequency of cleaning depends on the operating environment: wet, smoky or particularly dirty surroundings can cause more accumulation of dirt on the optics of the device.

- Clean with a soft cloth using our lamp and lens cleaner (item no. 280122).
- Always dry the parts carefully.

Fan grids

The fan grids of the device must be cleaned on a regular basis to remove dust and dirt. Before cleaning, switch off the device and disconnect AC-powered devices from the mains. Use a lint-free damp cloth for cleaning. Never use solvents or alcohol for cleaning.



9 Protecting the environment

Disposal of the packaging material



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose these materials with your normal household waste, but make sure that they are fed to a recovery. Please follow the notes and markings on the packaging.

Disposal of batteries



Batteries must not be disposed of as domestic waste or thrown into fire. Dispose of the batteries according to national or local regulations regarding hazardous waste. To protect the environment, dispose of empty batteries at your retail store or at appropriate collection sites.

Disposal of your old device



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose with your normal household waste.

Dispose this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.



