## th•mann

## **Exclusive Monitor Stand**



- Monitor shelf board decoupled from the lower part of the stand due to 4 rubber feet and elastic foam surface
- Especially for absorption of low frequencies
- Polyester foam (45 kg/m<sup>3</sup>) with flocked surface consisting of 4 individual parts with an airgap of 10 cm in the centre
- Centric load: max. 30 kg
- Material:

*Exclusive Monitor Stand A100 Oak (item no. 491311):* Solid oak

*Exclusive Monitor Stand A100 WH (item no. 491290):* White lacquered MDF

*Exclusive Monitor Stand Eco A100 Oak (item no. 494618):* 25 mm plastic-coated board with wooden look

*Exclusive Monitor Stand Eco A100 WH (item no. 494615):* 25 mm plastic-coated board with wooden look

Colour:

Exclusive Monitor Stand A100 Oak (item no. 491311): Oak

*Exclusive Monitor Stand A100 WH (item no. 491290):* White

Exclusive Monitor Stand Eco A100 Oak (item no. 494618): Oak

*Exclusive Monitor Stand Eco A100 WH (item no. 494615):* White

- Dimensions (W  $\times$  H  $\times$  D): 30 cm  $\times$  100 cm  $\times$  30 cm
- Weight:

Exclusive Monitor Stand A100 Oak (no. 491311):	14.4 kg
Exclusive Monitor Stand A100 WH (no. 491290):	14.4 kg
Exclusive Monitor Stand Eco A100 Oak (no. 494618):	12.7 kg
Exclusive Monitor Stand Eco A100 WH (no. 494615):	12.7 kg

This product is intended to be used to optimise the room acoustics. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.



Ensure that plastic bags, packaging, etc. are properly disposed of and are not in the reach of babies and young children. Choking hazard!

The plasticiser contained in the rubber feet of this product may possibly react with the coating of your parquet, linoleum, laminate or PVC floor and after some time cause permanent dark stains. In case of doubt, do not put the rubber feet directly on the floor, but use felt-pad floor protectors or a carpet.



For the packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

Thomann GmbH · Hans-Thomann-Straße 1 · 96138 Burgebrach · Germany · www.thomann.de