



Change frequency

Automatically/Scan



Manually




Sync




Sensitivity


- 0 dB
- 10 dB
- 20 dB
- 30 dB




ME 2-2



ME 3-II



Min. distance



SKM



Guitar pickup




Multichannel

Bank 1...8
Ch. 0...9

Bank	Ch.	Bank	Ch.	Bank	Ch.	Bank	Ch.	
2	3	2	4	2	5	2	6	✓
1	1	1	2	1	3	1	8	✓
2	3	1	3	4	7	8	9	✗
2	3	2	3	2	3	2	3	✗

Squelch



XS WIRELESS 1


Quick Guide

Kurzanleitung | Guide rapide | Guida rapida | Guia de inicio rápido | Guia rápido | Beknopte handleiding | Krótka instrukcja obsługi | Snabbguide | Quickguide | Quick Guide | Γρήγορος οδηγός | Краткая инструкция | 快速指南 | 요약 설명서


In the box

XS WIRELESS 1	Vocal Sets		Instrument Sets		Lavalier Set	Headmic Set
	XSW 1-825	XSW 1-835	XSW 1-CI1	XSW 1-908	XSW 1-ME2	XSW 1-ME3
EM-XSW 1	•	•	•	•	•	•
NT 12-5CW						
SKM 825-XSW	•	•	•	•	•	•
MZQ 1	•	•	•	•	•	•
SKM 835-XSW	•	•	•	•	•	•
SK-XSW	•	•	•	•	•	•
e 908T	•	•	•	•	•	•
ME 2-2	•	•	•	•	•	•
ME 3-II	•	•	•	•	•	•
CI 1-N	•	•	•	•	•	•
2 x AA LR6 1.5	•	•	•	•	•	•


Battery



Low battery




Setup




On/off



Display



Volume



Mute

