

TL6000 Torch Lamp

Quick Start Guide

This quick start guide contains important information on the safe operation of the device. Read and follow the safety advice and instructions given. Retain the quick start guide for future reference. If you pass the device on to others please include this quick start guide.

Safety instructions

Intended use

This device is used for the wireless transmission of audio signals. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

Danger for children



Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke! Never let unattended children use electrical devices.

Risk of fire due to incorrect polarity

Incorrectly inserted batteries may destroy the device or the batteries. Ensure that proper polarity is observed when inserting batteries.

Possible damage by leaking batteries

Leaking batteries can cause permanent damage to the device. Take batteries out of the device if it is not going to be used for a longer period.

Where to use the product

Never use the product

- in direct sunlight
- in conditions of extreme temperature or humidity
- in extremely dusty or dirty areas
- at locations where the unit can become wet
- near magnetic fields

General handling

- To prevent damage, never use force when operating the switches and controls.
- Never immerse the appliance in water. Just wipe it with a clean dry cloth. Do not use liquid cleaners such as benzene, thinners or flammable cleaning agents.

Keep foreign substances from the unit!

Keep the device away from containers with liquids. Should any liquid get into the unit, this could lead to its destruction or fire. Be sure not to let any metal objects into the unit.

Features

- LED flashlight with zoom function
- Six different light modes: (100% / 50% / 15% / stroboscope / SOS)
- Robust aluminium housing
- Even light distribution
- Easy handling thanks to the large button and sliding focus
- Including hand strap and nylon belt holster
- Operation with 3 × AAA batteries (not included)

Using the device

1. Unscrew the cap from the flashlight handle and remove the battery holder.
2. Insert 3 × AAA batteries (not included), observing the polarity indicated on the battery holder.
3. Push the assembled battery holder back into the handle and turn the cap hand-tight.
4. Press the switch to turn on the light. Tap the switch to set 5 modes: Full | Medium | Low | Stroboscope | SOS.
5. The flashlight has a zoom of 10° to 75°. You can adjust it by sliding the lamp head.
6. To turn off the light, hold the switch for one second.
7. Should the light output decrease significantly, the batteries are exhausted and must be replaced. The flashlight is then ready for use again.
8. We recommend using the included hand strap to avoid accidental dropping.



Technical data

Beam angle	10° - 75°
Light output 10° / 1 m	3900 lx
Colour temperature	10300 K
Light duration	> 8 hours @ full power
Diameter handle	29 mm
Diameter lens	41 mm
Overall length	139 mm - 158 mm
Weight w/o batteries	152 g



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.



Batteries must not be disposed of as domestic waste or thrown into fire. Dispose of batteries according to national or local regulations regarding hazardous waste. Dispose of empty batteries at appropriate collection sites.



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.