





WS 110  
MCM windscreen soft

KK 14  
MCM capsule head KK 14 cardioid

SH 150  
MCM gooseneck 150 mm

KC 1  
MCM cable brace

AC 31  
MCM cable mini jack 1.8 m

MCM 100 (works with AC 31 only)  
MCM output stage XLR

optional accessories:

- AC 32  
MCM cable LEMO 3 pin 1.8 m
- AC 33  
MCM cable MicroDot 1.8 m
- AC 34  
MCM cable mini XLR 4 pin 1.8 m

bodypack transmitter

MC 1  
MCM clip high strings

MC 2  
MCM strings clip cello

MC 3  
MCM strings clip double bass

MC 4  
MCM rib clip double bass

MC 5  
MCM universal strap clip

MC 6  
MCM universal clamp clip

MC 7  
MCM clip drum rims

MC 8  
MCM magnetic piano clip

MC 9  
MCM clip guitar