



CLBW Wireless Foot Switch

Quick start guide

This quick start guide contains important information on the safe operation of the product. Read and follow the safety advice and instructions given. Retain the quick start guide for future reference. If you pass the product on to others please include this quick start quide.

Safety instructions

Intended use

This device is intended to be used as wireless remote control for compatible CLB lighting sets. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

Danger for children



Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts from the product. They could swallow the pieces and choke! Never let children unattended use electrical devices.

Notes on wireless transmission

This device utilizes a frequency range that is free of charge and registration within the European Union (EU). For more information, please visit: http://www.thomann.de. Make sure that there are no metal objects between the transmitter and receiver. Avoid interference from other radio systems.

Risk of fire due to incorrect polarity

Incorrectly inserted batteries may destroy the device or the batteries. Ensure that proper polarity is observed when inserting batteries.

Possible damage by leaking batteries

Leaking batteries can cause permanent damage to the device.

Take batteries out of the device if it is not going to be used for a longer period.

Electromagnetic compatibility with other electrical equipment Using the device near radios or TV sets may cause interference. Then increase the distance between the devices.

Where to use the product

Never use the product

- in conditions of extreme temperature or humidity
- in extremely dusty or dirty areas
- · at locations where the unit can become wet

General handling


- To prevent damage, never use force when handling the product.
- Never immerse the product in water. Just wipe it with a clean dry cloth. Do not use liquid cleaners such as benzene, thinners or flammable cleaning agents.
- · Disconnect the device from the mains power supply when it is not in use.

Features

- Foot remote control for compatible CLB light sets:
- Stairville CLB5 6P RGB WW Compact LED Bar (item no. 460583)
- Stairville CLB5 RGB WW Compact LED Bar 5 (item no. 419587)
- Stairville CLB8 RGBW Compact LED Bar 8 (item no. 333919)
- Stairville Crazy Par Bundle 4 8x5W RGBWAP (item no. 431677) Stairville CLB5 2P RGB WW Compact LED Bar (item no. 448711)
- \bullet Use the 4 switches for selecting different modes (Auto Run, Sound Active, Freeze and Blackout).
- Operates over the supplied 9-V power adapter or a 9-V block battery (not supplied)

Using the product

- 1. Set the [On/Off] switch to the On position to turn on the unit. The red LED lights up. When the device receives radio signals, the green LED flashes.
- 2. Press [Auto Run/Program] to activate the automatic mode. Press [Auto Run/Program] repeatedly to cycle through the 14 available programmes. The respective programme then starts right away.
- 3. Press [Sound Active] to activate the sound control.
- 4. Press [Freeze] to pause the current show. Press [Freeze] again to resume the show
- 5. Press [Blackout] to turn all LEDs off. Press [Blackout] again to disable the blackout.



Technical specifications

Input connection Socket for power adapter

External power adapter, 100 - 240 V, ~ 50/60 Hz Power supply

9 V == / 1 A, centre positive Operating voltage

2.4 GHz Frequency of operation 100 mW Max. transmission power Transmission range 500 m

Battery type Battery Carbon block battery

Voltage 9 V Capacity 800 mAh Degree of protection

Dimensions (W \times H \times D) $430.5 \text{ mm} \times 71 \text{ mm} \times 152.5 \text{ mm}$

Weight 1.64 kg

Ambient conditions Temperature range 0 °C ... 40 °C

Relative humidity 20 % ... 80 % (non-condensing)



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.



Batteries must not be disposed of as domestic waste or thrown into fire. Dispose of batteries according to national or local regulations regarding hazardous waste. To protect the environment, dispose of empty batteries at your retail store or at appropriate collection sites.

