


electro-harmonix

IMPORTANT SAFETY INSTRUCTIONS

- Read and keep these instructions
- Heed all warnings
-  Device and packaging may contain small parts which may be a choking hazard. Not suitable for children under the age of three.
- To avoid danger of suffocation, keep plastic packing material away from babies and children and dispose of properly. Do not use packing materials in cribs, beds, carriages or playpens.
- This musical instrument device is intended to be used as an accessory with other musical instruments and may only produce sound when paired with a musical instrument and amplifier. The device is intended to be operated in any location in which musical instruments are typically found. Any use of this device in other operating conditions is considered improper.
- This device is capable of producing, or enabling, very high sound pressure levels which may cause temporary or permanent hearing damage.
- Follow all instructions
- Clean only with a dry cloth
- Use care when adjusting volume levels during use.
- Rubber bumpers may cause staining.
- The device may only be used with proper and adequate power supplies as detailed in the device's instruction manual. Power supplies that are underpowered or exceed specified voltages may cause damage to the device.
- Use of power supplies with the incorrect polarity is a fire hazard and may damage the device.
- Connecting improper power supplies to the device may cause an electric shock hazard.
- Keep away from fire, water, and high voltage equipment.
- For devices that take battery power, do not short circuit the nodes of the battery.
- A short circuit to high voltage equipment may produce an electric shock.



The CE logo indicates that this product has been tested and shown to conform with all applicable European Conformity directives.



The WEEE or "trashcan" logo indicates that this product is made up of electronic components that should not be disposed of alongside household waste but instead should be recycled by a proper electrical waste facility.



Dispose of packaging materials according to the rules of your local jurisdiction.



Dispose of depleted batteries according to the rules of your local jurisdiction.



In France, packaging elements are to be separated and placed in the appropriate bin.



This device, its accessories, and batteries can be recycled in France.

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !