

Frequency (740.2-751.8Mhz)

CHANNEL 1	740.625MHz	CHANNEL 9	746.625MHz
CHANNEL 2	741.375MHz	CHANNEL 10	747.250MHz
CHANNEL 3	742.375MHz	CHANNEL 11	747.875MHz
CHANNEL 4	743.125MHz	CHANNEL 12	748.500MHz
CHANNEL 5	743.750MHz	CHANNEL 13	749.375MHz
CHANNEL 6	744.375MHz	CHANNEL 14	750.125MHz
CHANNEL 7	745.250MHz	CHANNEL 15	750.875MHz
CHANNEL 8	745.875MHz	CHANNEL 16	751.500MHz