

Safety Instruction (ENGLISH)

Choking Hazard

This product contains small parts that may present a choking hazard if swallowed, especially for young children. Keep all small components, including plastic covers and packaging materials, out of reach of children. To prevent suffocation and choking hazards, ensure that all plastic covers and packaging are disposed of properly.

Intended Use

This product is designed for specific uses only. It is to enhance and shape the sound of the guitar. Any usage outside the described purpose or under non-standard operating conditions may be hazardous and is considered improper use. Improper use can lead to product damage or personal injury.

Battery Hazards

Batteries must be handled with care to avoid potential leakage, which may damage the product and pose a safety risk. Always install batteries according to the correct polarity (+/-). Failure to do so may result in fire, product damage, or injury. Use only the recommended battery type for this device.

Disposal of the Packaging Material



To ensure environmental safety, recycle packaging materials according to local regulations. For electrical and electronic waste, please follow your country's guidelines and disposal regulations for Waste Electrical and Electronic Equipment (WEEE). Improper disposal may harm the environment.

Disposal of Batteries



Do not dispose of batteries in household waste. Used batteries must be recycled or disposed of at a designated collection point in accordance with local regulations. Improper disposal of batteries may cause harm to the environment and health. Please consult local waste management authorities for battery disposal guidelines.

Disposal of your Old Device



This device is classified as Waste Electrical and Electronic Equipment (WEEE) and must not be disposed of as regular household waste. Instead, it should be taken to an authorized recycling center for safe and environmentally responsible disposal. For more information on proper disposal, contact your local waste disposal authority.

Disposal of the Manual



The paper manual should be recycled where paper recycling facilities are available. If recycling is not possible, dispose of it in accordance with your local waste disposal regulations. Electronic versions of this manual can also be accessed online, minimizing paper waste.

Manufacturer: Artecsound Co., Ltd.

3 Samsung-ro 221 Beon-gil, Deogyang-gu, Goyang-si, Gyeonggi-do, 10583, KOREA

Tel: +82 2 381 7322 Fax: +82 2 381 7330