



Gibson®


ASSEMBLY INSTRUCTIONS





STEP 1




STEP 2



STEP 3



STEP 4



STEP 5

	Ax1PC		Bx1PC		Cx1PC		Fx1PCS		Kx1PC		Lx2PCS
	Dx1PC		Ex1PC		Lx2PCS		Gx4PCS		Hx4PCS		Jx4PCS