



# G112 guitar cabinet



user manual

Musikhaus Thomann Thomann GmbH Hans-Thomann-Straße 1 96138 Burgebrach Germany Telephone: +49 (0) 9546 9223-0 E-mail: info@thomann.de Internet: www.thomann.de

06.03.2017, ID: 139026

# **Table of contents**

1	General notes	. 4
2	Safety instructions	
3	Features	
4	Installation and starting up	
	4.1 Tips on handling speakers	10
	4.2 Pin assignment	11
5	Connections and operating elements	
6	Technical specifications	
7	Protecting the environment	



# 1 General notes

	This user manual contains important information on safe operation of the device. Read a follow all safety notes and all instructions. Save this manual for future reference. Make su that it is available to all persons using this device. If you sell the device to other users, be that they also receive this manual.	
	Our products are subject to a process of continuous development. We therefore reserve the right to make changes without notice.	
Symbols and signal words	This section provides an overview of the symbols and signal words used in this user manual.	



Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a pos- sible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a pos- sible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – danger zone.

G112



### 2 Safety instructions

#### Intended use

This device is intended to be used in a sound reinforcement system. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Safety



### DANGER!

### Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.

th•mann MUSIC IS OUR PASSION



### CAUTION!

### Possible hearing damage

The device can produce volume levels that may cause temporary or permanent hearing impairment. Over an extended period of time, even levels that seem to be uncritical can cause hearing damage.

Decrease the volume level immediately if you experience ringing in your ears or hearing impairment. If this is not possible, keep a greater distance or use sufficient ear protectors.



### NOTICE!

### **Operating conditions**

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.

MUSIC IS OUR PASSION

### 3 Features

Special features of this powerful guitar cabinet:

- Input: 1 × 1/4" phone socket
- Power handling: 100 watt, 8 Ω
- Half-open MDF housing with carrying handle



### 4 Installation and starting up

Unpack and carefully check that there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.



#### NOTICE!

#### Possible property damage by magnetic fields

Loudspeakers produce a static magnetic field. Therefore, maintain an appropriate distance to devices that can be adversely affected or damaged by an external magnetic field.

### 4.1 Tips on handling speakers

We recommend you to set up the speakers in a way, that the sound signals can reach the audience unobstructedly.

Always use high grade cable to connect your equipment. Otherwise you won't reach maximum sound quality.

For optimum results, both impedance and power handling of the speaker must match the requirements of the amplifier/input signal. Always follow the corresponding technical specifications of all devices involved! The overall impedance of the connected loudspeakers must not deceed the minimum output impedance of the amp. The amps RMS output power should be 50 % above the power handling capacity of the connected speakers.

If you notice distortion during operation, either the amp or the speaker is overloaded. This may permanently damage the amp or the speaker. Always reduce the volume as soon as you hear distortion.

thomann MUSIC IS OUR PASSION

### 4.2 Pin assignment

### 1/4" phone jack for signal input




Drawing and table indicate the pin assignment of a 1/4" TS phone jack to be used.

1	Signal
2	Ground, shielding

th.mann

# 5 Connections and operating elements



1 Signal input (1/4" phone socket)



# 6 Technical specifications

System	Passive guitar cabinet
Speakers	1 × 12" woofer
Power handling	100 Watt (Peak) / 60 W (RMS)
Impedance	8Ω
Connection	1/4" phone socket
Dimensions (W $\times$ H $\times$ D)	545 mm × 257 mm × 453 mm
Weight	12.5 kg

th.mann

### 7 Protecting the environment

Disposal of the packaging material



#### Disposal of your old device



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE). Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

Musikhaus Thomann • Hans-Thomann-Straße 1 • 96138 Burgebrach • Germany • www.thomann.de