





Musikhaus Thomann Thomann GmbH Hans-Thomann-Straße 1 96138 Burgebrach Germany Telephone: +49 (0) 9546 9223-0 E-mail: info@thomann.de Internet: www.thomann.de

01.03.2016, ID: 196592 (V2)

# **Table of contents**

1	General information	. 4
	1.1 Further information	5
	1.2 Notational conventions	6
	1.3 Symbols and signal words	6
2	Safety instructions	. 8
3	Features	10
4	Installation and starting up	11
5	Connections and controls	12
6	Technical specifications	14
7	Plug and connection assignment	15
8	Protecting the environment	16

# 1 General information

This manual contains important instructions for the safe operation of the unit. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the device. If you sell the unit please make sure that the buyer also receives this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change.



### 1.1 Further information

On our website (<u>www.thomann.de</u>) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.

### **1.2 Notational conventions**

This manual uses the following notational conventions:

Letterings

The letterings for connectors and controls are marked by square brackets and italics. **Examples:** [VOLUME] control, [Mono] button.

### **1.3** Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.



Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a pos- sible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a pos- sible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – danger zone.



# 2 Safety instructions

#### Intended use

This device is intended to be used in a sound reinforcement system. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Safety



### DANGER!

#### Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.





### CAUTION!

### Possible hearing damage

The device can produce volume levels that may cause temporary or permanent hearing impairment. Over an extended period of time, even levels that seem to be uncritical can cause hearing damage.

Decrease the volume level immediately if you experience ringing in your ears or hearing impairment. If this is not possible, keep a greater distance or use sufficient ear protectors.



#### NOTICE!

#### **Operating conditions**

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.





## 3 Features

Special features of this monitor:

- Passive 2-way monitor
- Highly efficient driver
- Powerful 12" woofer
- 1" compression driver with 1.75" titanium membrane
- Computer optimized VCD horn for optimum sound dispersion
- Excellent speech intelligibility
- Output for further monitors



### 4 Installation and starting up

Unpack and carefully check that there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.




#### NOTICE!

#### Possible property damage by magnetic fields

Loudspeakers produce a static magnetic field. Therefore, maintain an appropriate distance to devices that can be adversely affected or damaged by an external magnetic field.



# 5 Connections and controls





1		[INPUT]
		Lockable NL4 input socket.
2	2	[OUTPUT]
		Lockable NL4 output socket to feed the audio signal to another monitor.



# **6** Technical specifications

System	Passive 2-way monitor
Housing	Multiplex, 15 mm, black
Speakers	12" woofer, 1" compression driver, VCD horn
Power handling	800 W
Impedance	8Ω
Frequency response	65 Hz 18 kHz (–3 dB)
	60 Hz 20 kHz (–10 dB)
Sound pressure level, 1 m distance	95 dB
Dispersion angle (V $\times$ H)	55° – 100° × 50°
Connections	2 × NL4, 1+/1-
Dimensions (W $\times$ H $\times$ D)	400 mm $\times$ 540 mm $\times$ 410 mm (19.7 in. $\times$ 6.2 in. $\times$ 14.6 in.)
Weight	15 kg

passive 2-way monitor

th•mann


### 7 Plug and connection assignment

#### Introduction

This chapter will help you select the right cables and plugs to connect your valuable equipment in such a way that a perfect sound experience is ensured.

Please note these advices, because especially in 'Sound & Light' caution is indicated: Even if a plug fits into the socket, an incorrect connection may result in a destroyed power amp, a short circuit or 'just' in poor transmission quality!

#### NL4 mounting connectors



1,+	Signal 1 (in phase)
1, –	Signal 1 (180 degree phase shift)
2, +	Signal 2 (in phase)
2, –	Signal 2 (180 degree phase shift)



# 8 Protecting the environment

Disposal of the packaging material



#### Disposal of your old device



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE). Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.





Musikhaus Thomann • Hans-Thomann-Straße 1 • 96138 Burgebrach • Germany • www.thomann.de