



BLS-315 Pro Lighting
Stand B
speaker / light stand

Musikhaus Thomann
Thomann GmbH
Hans-Thomann-Straße 1
96138 Burgebrach
Germany
Telephone: +49 (0) 9546 9223-0
E-mail: info@thomann.de
Internet: www.thomann.de

24.08.2015, ID: 287838

Table of contents

1	General information	4
	1.1 Further information.....	5
	1.2 Notational conventions.....	6
	1.3 Symbols and signal words.....	6
2	Safety notes	8
3	Features	11
4	Operating	12
5	Technical specifications	17
6	Protecting the environment	18

1 General information

This manual contains important instructions for the safe operation of the product. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the product. If you sell the unit, please make sure that the buyer also receives this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change.

1.1 Further information

On our website (www.thomann.de) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.

1.2 Notational conventions

This manual uses the following notational conventions:

Instructions


The individual steps of an instruction are numbered consecutively. The result of a step is indented and highlighted by an arrow.

Example:

1. ▶ Switch on the device.
2. ▶ Press *[Auto]*.
 - ⇒ Automatic operation is started.
3. ▶ Switch off the device.

1.3 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – danger zone.

2 Safety notes

Intended use

This speaker / light stand is used for stable fixing and height-adjustable installation of loud-speaker cabinets and lights. Use the product only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This product may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this product only if they are supervised or instructed by a person who is responsible for their safety.

Safety**DANGER!****Danger for children**

Ensure that plastic bags, packaging, etc. are properly disposed of and are not in the reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the product. They could swallow the pieces and choke!

Never let children play unattended with the product.

**CAUTION!****Danger of tipping when transported under load**

If the stand is moved without having removed the installed device, the stand may tip over and cause injuries and property damage.

Remove the installed device before transporting the stand.



CAUTION!

Danger of tipping on unsuitable surfaces

When the speaker stand is installed on soft or uneven ground, the stand may tip over and cause injuries and property damage.

Install the stand only on even and solid surfaces.



CAUTION!

Danger of tipping due to overload

In case of overload, the stand may tip over and cause injuries and property damage.

Never exceed the maximum load capacity specified for the stand.

3 Features

Professional speaker and light stand

- Material: Steel / magnesium compound
- Individually reinforced legs for high stability
- Height: 150 to 315 cm
- Stand space diameter 120 cm
- Pipe diameter: 28 mm
- 35 mm adapter for suitable speaker box
- Centric load capacity up to 30 kg
- Made in Europe

4 Operating

Unpack and check carefully there is no transportation damage before using the product. Keep the equipment packaging. To fully protect the product against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.



CAUTION!

Danger of tipping when transported under load

If the stand is moved without having removed the installed device, the stand may tip over and cause injuries and property damage.

Remove the installed device before transporting the stand.



CAUTION!

Danger of tipping on unsuitable surfaces

When the speaker stand is installed on soft or uneven ground, the stand may tip over and cause injuries and property damage.

Install the stand only on even and solid surfaces.



CAUTION!

Danger of tipping due to overload

In case of overload, the stand may tip over and cause injuries and property damage.

Never exceed the maximum load capacity specified for the stand.



NOTICE!

Possible staining

The plasticiser contained in the rubber feet of this product may possibly react with the coating of your parquet, linoleum, laminate or PVC floor and after some time cause permanent dark stains.

In case of doubt, do not put the rubber feet directly on the floor, but use felt-pad floor protectors or a carpet.

Setting up



1. ➤ Unfold the feet of the tripod until the cross braces are in a horizontal position.
2. ➤ Fix this position with the safety screw on the slider to which the three feet are attached.
3. ➤ Pull out the two safety pin and loosen the two safety screws on the extension tubes.
4. ➤ Pull out the upper extension tube to the desired height and slide the safety pin through the corresponding grid hole.
5. ➤ Fix the position of the upper extension tube with the safety screw on the upper tube clamp.
6. ➤ Pull out the lower extension tube to the desired height and slide the safety pin through the corresponding grid hole.
7. ➤ Fix the position of the lower extension tube with the safety screw on the lower tube clamp.
8. ➤ Mount a spotlight or a speaker box. If necessary, screw the supplied adapter firmly to the upper extension tube. Observe the instructions of the respective manufacturers. The maximum load capacity of 30 kg in total must not be exceeded.

Dismounting

- 1.** ▶ Remove spotlight or speaker box.
- 2.** ▶ Pull out the safety pin on the lower extension tube.
- 3.** ▶ Loosen the safety screw on the lower tube clamp and slide the lower extension tube all the way down.
- 4.** ▶ Tighten the safety screw on the lower tube clamp.
- 5.** ▶ Pull out the safety pin on the upper extension tube.
- 6.** ▶ Loosen the safety screw on the upper tube clamp and slide the lower extension tube all the way down.
- 7.** ▶ Tighten the safety screw on the upper tube clamp.
- 8.** ▶ If necessary, take off the adapter.
- 9.** ▶ Loosen the safety screw on the slider to which the three feet are attached.
- 10.** ▶ Fold up the feet of the tripod.
- 11.** ▶ Pack all parts of the system in their original package, as possible, and store the package in a dry place protected against moisture.

5 Technical specifications

Material	Steel / magnesium compound
Permitted centric loadability	30 kg
Minimum support height	150 cm
Maximum support height	310 cm
Pipe diameter	28 mm diameter
Tripod flange adapter	35 mm diameter
Weight	5.6 kg
Transport length when folded	124 cm
Colour	Black

6 Protecting the environment

Disposal of the packaging material



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.



