

USER MANUAL





Powerslide 4



Table of contents

1.	Saf	ety instructions	3
1.	.1.	FOR SAFE AND EFFICIENT OPERATION	3



1. Safety instructions

- This device is suitable for indoor use only.
- All modifications to the device will void the warranty.
- Repairs are to carry out by skilled personnel only.
- Use only fuses of the same type and original parts as spare parts.
- Protect the unit from rain and humidity to avoid fire and electric shocks.
- Make sure to unplug the power supply before opening the housing.

1.1. FOR SAFE AND EFFICIENT OPERATION

Be careful with heat and extreme temperature

Avoid exposing it to direct rays of the sun or near a heating appliance.

Not put it in a temperature bellow 32 F / 0 C, or exceeding 131 F / 55 C.

Keep away from humidity, water and dust

Do not place the set in a location with high humidity or lots of dust.

Containers with water should not be placed on the set.

Keep away from sources of hum and noise

Such as transformer motor, tuner, TV set and amplifier.

To avoid placing on un-stable location

Select a level and stable location to avoid vibration.

Do not use chemicals or volatile liquids for cleaning

Use a clean dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

If out of work, contact sales agency immediately

Any troubles arose, remove the power plug soon, and contact with an engineer for repairing, do not open the cabinet by yourself, it might result a danger of electric shock.

Take care with the power cable

Never pull the power cable to remove the plug from the receptacle, be sure to hold the plug. When not using the device for an extended period of time, be sure to disconnect the plug from the receptacle.



Important: Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not accept liability for any resulting defects or problems. Make sure the electrical connection is carried out by qualified personnel. All electrical and mechanical connections have to be carried out according to the European safety standards.

2. Usage

The Power Slide Bar is a slide bar with dmx and powerconnector. They are connected internal.

3. Plugs



1)	Powercon IN	Main power connection
2)	DMX IN	3Pol XLR Plug for connecting the dmx signal from the console.
3)	Fuse	Push Fuse, after overpowering please push it back
4)	EU Plug 1	to connect an item with power

,	•	•
5)	DMX OUT 1	Please connect the DMX IN of your item here
6)	DMX IN 1	Please connect the DMX OUT of your item here
7)	EU Plug 2	to connect an item with power

8) [DMX OUT 2	Please connect the DMX IN of your item here
9) [DMX IN 2	Please connect the DMX OUT of your item here
10) E	EU Plua 3	to connect an item with power

10) LO 1 lug 3	to connect an item with power
11) DMX OUT 3	Please connect the DMX IN of your item here
12) DMX IN 3	Please connect the DMX OUT of your item here

13) EU Plug 4	to connect an item with power
14) DMX OUT 4	Please connect the DMX IN of your item here
15) DMX IN 4	Please connect the DMX OUT of your item here

16) DMX OUT main from here you can connect the DMX Signal to the next Bar or item. 17) Powecon Out From here you can connect the power to the next bar or item.

4. Slide function

The slide Bar is constructed that you can move every safety bolt and every screw. To do so, please unscrew the screws or safety bolts a bit and move the hex head nut in the profile line. Please screw It tight again after you moved it.



5. Technical data

Connection Powercon IN/OUT

4 x EU Plug with cover

4 x DMX 3pol IN/OUT (Neutrik)

Including Fuse

Installation 6 screws

2 Eye bolts

Measures 1500 x 150 x 75kg

Weight 4,5kg
Protection Class IP20



Importer:

B&K Braun GmbH Industriestraße 1 D-76307 Karlsbad-Ittersbach

> www.bkbraun.com info@bkbraun.com





