

## Voice-Liste

Nr.	Name
<b>KICK</b>	
1	Standard Kick 1
2	Standard Kick 2
3	Room Kick
4	Rock Kick 1
5	Rock Kick 2
6	Acoustic Kick
7	HipHop Kick
8	Funk Kick
9	Jazz Kick 1
10	Jazz Kick 2
11	Electronic Kick
12	808 Kick
13	House Kick 1
14	House Kick 2
<b>SNARE</b>	
15	Classic Snare 1
16	Classic Snare Rim 1
17	Classic Snare 2
18	Classic Snare Rim 2
19	Room Snare 1
20	Room Snare 2
21	Acoustic Snare
22	Acoustic Snare Rim
23	Funk Band Snare
24	Funk Band Rim
25	Camco Snare
26	Camco Snare Rim
27	Brush Snare
28	Brush Snare Rim
29	Electronic Snare 1
30	Electronic Snare 2
31	808 Snare
32	House Snare 1
33	House Snare 2
<b>TOM</b>	
34	Classic Tom 1
35	Classic Tom 2
36	Classic Tom 3
37	Classic Tom 4
38	Classic Tom 5
39	Classic Tom 6
40	Camco Tom 1
41	Camco Tom 2
42	Camco Tom 3
43	Camco Tom 4
44	Camco Tom 5
45	Camco Tom 6
46	808 Tom 1
47	808 Tom 2
48	808 Tom 3
49	808 Tom 4
50	808 Tom 5
51	808 Tom 6
52	Electronic Tom 1
53	Electronic Tom 2
54	Electronic Tom 3
55	Electronic Tom 4
56	Electronic Tom 5
57	Electronic Tom 6

Nr.	Name
<b>RIDE</b>	
58	Classic Ride
59	Classic Ride Bell
60	Rock Ride
61	808 Ride
<b>CRASH</b>	
62	Standard Crash 1
63	Standard Crash 2
64	Rock Crash
65	Splash 1
66	Splash 2
67	Brush Crash
68	808 Crash
<b>HI-HAT</b>	
69	Standard Hi-hat Open
70	Jazz Hi-hat Open
71	Electronic Hi-hat Open
72	808 Hi-hat Open
73	Standard Hi-hat Close
74	Jazz Hi-hat Close
75	Electronic Hi-hat Close
76	808 Hi-hat Close
77	Standard Hi-hat Pad
78	Jazz Hi-hat Pad
79	Electronic Hi-hat Pad
80	808 Hi-hat Pad
<b>PERCUSSION</b>	
81	Bongo High
82	Bongo Low
83	Mute Conga Hi-hat
84	Open Conga Hi-hat
85	Conga Low
86	Timbale High
87	Timbale Low
88	Agogo High
89	Agogo Low
90	Cabasa
91	Maracas
92	Short Whistle
93	Long Whistle
94	Short Guiro
95	Long Guiro
96	Claves
97	Wood Block High
98	Wood Block Low
99	Mute Cuica
100	Open Cuica
101	Mute Triangle
102	Open Triangle
103	Shaker
104	Jingle Bell
105	Belltrees
106	Castanets
107	Mute Surdo
108	Open Surdo