



Manual

**Fog machine Miniblast**  
**LED Amber**

## Table of contents

1. Safety instructions .....	3
1.1. Instructions for a safe and efficient operation.....	3
1.2. More information on safe use .....	4
2. Introduction.....	5
3. Control.....	5
4. Technical data .....	6

## 1. Safety instructions



- This Device is suitable for indoor use only.
- All modifications will void the warranty.
- Repairs have to be carried out by skilled personnel only.
- Only use fuses of the same type and original parts as spare parts.
- Protect the Unit from rain and humidity to avoid fire and electric shocks.
- Make sure to unplug the power supply before opening the housing.

### 1.1. Instructions for a safe and efficient operation

#### **Be careful with heat and extreme temperature**

Only use the device in a place where no extreme temperatures will occur.

Do not keep it in a temperature below 32°F /0°C, or exceeding 104°F /40°C.

Avoid exposing it to direct rays of the sun or near a heating appliance.

#### **Keep away from humidity, water and dust**

Do not place the set in a location with high humidity or lots of dust.

Containers with liquid should not be placed on the set.

#### **Avoid placing it on un-stable location**

Select a level and stable location to avoid vibration.

#### **Do not use chemicals or volatile liquids for cleaning**

Use a clean dry cloth to wipe off the dust. Metal Parts can be cleaned with a wet soft cloth for stubborn dirt.

#### **If out of work, contact sales agency soon**

If any troubles occurs, remove the power plug immediately, and contact with an engineer for repairing, do not open the cabinet by yourself, it might result a danger of electric shock.

#### **Take care with the power cable**

Never pull the power cable to remove the plug from the receptacle, be sure to hold the plug. When not using the device for an extended period of time, be sure to disconnect the plug from the receptacle.

#### **IMPORTANT:**

Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not accept liability for any resulting defects or problems. Make sure the electrical connection is carried out by qualified personnel. All electrical and mechanical connections have to be carried out according to the European safety standards.

## 1.2. More information on safe use

- Disconnect the unit from the electricity supply before refilling liquid.
- Only 3-prong grounded outlet is available for all the DSK models. Please make sure that the unit's voltage is within range of rated one.
- Keep the unit in upright position at any time.
- This unit is for adults use only. Keep away from children. Never leave the unit running unattended.
- The output smoke is very hot. Please keep at least 50cm away from the nozzle during operation.
- Never aim the output nozzle directly at people.
- Never aim the output nozzle at open flames.
- Please cool down the smoke machine before cleaning or maintaining it.
- Put the unit in a well-ventilated area. Never seal the unit's vents. Allow a free air space of at least 20cm around the sides and top of the unit to guarantee adequate ventilation.
- Never add any flammable liquids (such as oil, gas, perfume) to the smoke liquid.
- Only use high-quality, water-based liquid recommended by your distributor. Other fog liquids may cause clogging or spouting.
- Always make sure there is sufficient liquid in the tank. Operating this unit without liquid might cause damages to the pump as well as over-heating of the heater.
- Never drink the fog liquids. If it is ingested, connect with a doctor immediately. If the fog liquids come in contact with skins or eyes, rinse thoroughly with water.

Note: please pay attention to all the warning labels and instructions printed on the exterior of the unit.

## 2. Introduction

Thank you for buying the **Fog machine Miniblast LED Amber**.

For a successful installation and operation, please read this manual carefully.

## 3. Control

1. Switch the unit on, the unit starts heating-up. If the unit is ready the green LED on the remote control lights up.
2. Press the button. While pressing the button the unit will spray out fog. While spraying fog the 3 amber LED are lighting.
3. During operation it is possible that the unit start heating-up again to get the right temperature. Wait until the green LED on the remote control lights.
4. Make sure that always enough fluid is in the tank. If the unit runs out of fluid it could be damaged.
5. If the fog output is low or there is no fog output anymore or the unit makes an unusual noise power the unit off. Check the fluid, the fuse and the power cord. If you cannot solve the problems please get in contact with your dealer.

## 4. Technical data

<b>Power supply</b>	
Voltage	220-240V / 50-60Hz
Power consumption max.	410 W
<b>Light source</b>	
LM type	LED single color
Color spectrum	Amber
Power	3 W
Number / Power	3 x 1W
<b>Connections</b>	
Strom in	IEC
<b>Technical data</b>	
Ejection volume	14m <sup>3</sup> / min
Tank volume	300 ml
Warm-up time	8 minutes
<b>Hardware</b>	
Protections class	IP20
Suitability	Indoor
Dimensions	290 x 150 x 140 mm
Weight	1,8 kg



**Importer:**

**B & K Braun GmbH**  
**Industriestraße 2**  
**D-76307 Karlsbad**  
[www.bkbraun.com](http://www.bkbraun.com)  
[info@bkbraun.com](mailto:info@bkbraun.com)

