

**Voice List**

No.	Name
<b>Kick</b>	
1	22" Acoustic Kick 1
2	22" Acoustic Kick 2
3	24" Standard Kick
4	Brush Kick 1
5	Brush Kick 2
6	24" Jazz Kick
7	22" Rock Kick
8	Room Kick
9	Fusion Kick
10	1970's Kick
11	Vintage Kick
12	HipHop Kick
13	Reggae Kick
14	Big Band Kick
15	Old School Kick
16	Lo-Fi Kick
17	Junkyard Kick
18	Noise Kick
19	Drum & Bass Kick
20	808 Kick
21	909 Kick
22	Electronic Kick
23	Power Kick
24	Dance Kick
25	FX Mix Kick
26	Techno Kick
27	Magic Kick
<b>Snare</b>	
28	14" Acoustic Snare
29	14" Acoustic Snare Rim
30	14" Standard Snare
31	14" Standard Snare Rim
32	14" Funk Snare 1
33	14" Funk Snare Rim 1
34	14" Funk Snare 2
35	14" Funk Snare Rim 2
36	Brush Snare 1
37	Brush Snare Rim 1
38	Brush Snare 2
39	Brush Snare Rim 2
40	14" Jazz Snare
41	14" Jazz Snare Rim
42	14" Rock Snare
43	14" Rock Snare Rim
44	13" Damped Snare 1
45	13" Damped Snare 2
46	13" Damped Snare 3
47	Orchestra Snare
48	Orchestra Snare Rim
49	Room Snare
50	Room Snare Rim
51	Fusion Snare
52	Fusion Snare Rim
53	Big Band Snare
54	Big Band Snare Rim
55	Vintage Snare
56	Vintage Snare Rim
57	Live Snare
58	Live Snare Rim
59	Reggae Snare

No.	Name
60	Reggae Snare Rim
61	R&B Snare
62	R&B Snare Rim
63	808 Snare
64	808 Snare Rim
65	909 Snare
66	909 Snare Rim
67	Electronic Snare
68	Power Snare
69	Dance Snare
70	Dance Snare Rim
71	Old School Snare
72	Old School Snare Rim
73	House Snare
74	House Snare Rim
75	Lo-Fi Snare
76	Lo-Fi Snare Rim
77	Junkyard Snare
78	Junkyard Snare Rim
79	Noise Snare
80	Noise Snare Rim
81	Drum & Bass Snare
82	Drum & Bass Snare Rim
83	Techno Snare
84	Techno Snare Rim
85	Magic Snare
86	Magic Snare Rim
87	Acoustic Snare Stick
88	Standard Snare Stick 1
89	Brush Snare Stick
90	Standard Snare Stick 2
91	Rock Snare Stick 1
92	Rock Snare Stick 2
93	Live Snare Stick
94	Room Snare Stick
95	Fusion Snare Stick
96	808 Snare Stick
97	909 Snare Stick
98	Electronic Snare Stick
99	Old School Snare Stick
100	House Snare Stick
101	Lo-Fi Snare Stick
102	Junkyard Snare Stick
103	Noise Snare Stick
104	Techno Snare Stick
105	Brush Swirl
<b>Tom</b>	
106	Acoustic Tom 1
107	Acoustic Tom 1 Rim
108	Acoustic Tom 2
109	Acoustic Tom 2 Rim
110	Acoustic Tom 3
111	Acoustic Tom 3 Rim
112	Acoustic Tom 4
113	Acoustic Tom 4 Rim
114	Acoustic Tom 5
115	Acoustic Tom 5 Rim
116	Acoustic Tom 6
117	Acoustic Tom 6 Rim
118	Standard Tom 1
119	Standard Tom 1 Rim

No.	Name
120	Standard Tom 2
121	Standard Tom 2 Rim
122	Standard Tom 3
123	Standard Tom 3 Rim
124	Standard Tom 4
125	Standard Tom 4 Rim
126	Standard Tom 5
127	Standard Tom 5 Rim
128	Standard Tom 6
129	Standard Tom 6 Rim
130	Brush Tom 1
131	Brush Tom 1 Rim
132	Brush Tom 2
133	Brush Tom 2 Rim
134	Brush Tom 3
135	Brush Tom 3 Rim
136	Brush Tom 4
137	Brush Tom 4 Rim
138	Brush Tom 5
139	Brush Tom 5 Rim
140	Brush Tom 6
141	Brush Tom 6 Rim
142	Funk Tom 1
143	Funk Tom 1 Rim
144	Funk Tom 2
145	Funk Tom 2 Rim
146	Funk Tom 3
147	Funk Tom 3 Rim
148	Funk Tom 4
149	Funk Tom 4 R
150	Funk Tom 5
151	Funk Tom 5 Rim
152	Funk Tom 6
153	Funk Tom 6 Rim
154	Jazz Tom 1
155	Jazz Tom 1 Rim
156	Jazz Tom 2
157	Jazz Tom 2 Rim
158	Jazz Tom 3
159	Jazz Tom 3 Rim
160	Jazz Tom 4
161	Jazz Tom 4 Rim
162	Jazz Tom 5
163	Jazz Tom 5 Rim
164	Jazz Tom 6
165	Jazz Tom 6 Rim
166	Rock Tom 1
167	Rock Tom 1 Rim
168	Rock Tom 2
169	Rock Tom 2 Rim
170	Rock Tom 3
171	Rock Tom 3 Rim
172	Rock Tom 4
173	Rock Tom 4 Rim
174	Rock Tom 5
175	Rock Tom 5 Rim
176	Rock Tom 6
177	Rock Tom 6 Rim
178	Fusion Tom 1
179	Fusion Tom 2
180	Fusion Tom 3

**Voice List**

No.	Name
181	Fusion Tom 4
182	1970's Tom 1
183	1970's Tom 2
184	1970's Tom 3
185	1970's Tom 4
186	Vintage Tom 1
187	Vintage Tom 2
188	Vintage Tom 3
189	Vintage Tom 4
190	Vintage Tom 5
191	Vintage Tom 6
192	808 Tom 1
193	808 Tom 2
194	808 Tom 3
195	808 Tom 4
196	808 Tom 5
197	808 Tom 6
198	808 Tom Fx 1
199	808 Tom Fx 2
200	909 Tom 1
201	909 Tom 2
202	909 Tom 3
203	909 Tom 4
204	909 Tom 5
205	909 Tom 6
206	909 Tom 7
207	909 Tom 8
208	Electronic Tom 1
209	Electronic Tom 2
210	Electronic Tom 3
211	Electronic Tom 4
212	Electronic Tom 5
213	Electronic Tom 6
214	Electronic Tom 7
215	Electronic Tom 8
216	Power Tom 1
217	Power Tom 2
218	Power Tom 3
219	Power Tom 4
220	Power Tom 5
221	Power Tom 6
222	90's Power Tom 1
223	90's Power Tom 2
224	90's Power Tom 3
225	90's Power Tom 4
226	90's Power Tom 5
227	90's Power Tom 6
228	Lo-Fi Tom 1
229	Lo-Fi Tom 1 Rim
230	Lo-Fi Tom 2
231	Lo-Fi Tom 2 Rim
232	Lo-Fi Tom 3
233	Lo-Fi Tom 3 Rim
234	Lo-Fi Tom 4
235	Lo-Fi Tom 4 Rim
236	Lo-Fi Tom 5
237	Lo-Fi Tom 5 Rim
238	Lo-Fi Tom 6
239	Lo-Fi Tom 6 Rim
240	Junkyard Tom 1
241	Junkyard Tom 1 Rim

No.	Name
242	Junkyard Tom 2
243	Junkyard Tom 2 Rim
244	Junkyard Tom 3
245	Junkyard Tom 3 Rim
246	Junkyard Tom 4
247	Junkyard Tom 4 Rim
248	Junkyard Tom 5
249	Junkyard Tom 5 Rim
250	Junkyard Tom 6
251	Junkyard Tom 6 Rim
252	Noise Tom 1
253	Noise Tom 1 Rim
254	Noise Tom 2
255	Noise Tom 2 Rim
256	Noise Tom 3
257	Noise Tom 3 Rim
258	Noise Tom 4
259	Noise Tom 4 Rim
260	Noise Tom 5
261	Noise Tom 5 Rim
262	Noise Tom 6
263	Noise Tom 6 Rim
264	Techno Tom 1
265	Techno Tom 1 Rim
266	Techno Tom 2
267	Techno Tom 2 Rim
268	Techno Tom 3
269	Techno Tom 3 Rim
270	Techno Tom 4
271	Techno Tom 4 Rim
272	Techno Tom 5
273	Techno Tom 5 Rim
274	Techno Tom 6
275	Techno Tom 6 Rim
<b>Ride</b>	
276	21" Acoustic Ride
277	21" Acoustic Ride Edge
278	21" Acoustic Ride Bell
279	22" Standard Ride
280	22" Standard Ride Edge
281	22" Standard Ride Bell
282	Brush Ride 1
283	Brush Ride 2
284	20" Funk Ride
285	20" Funk Ride Edge
286	20" Funk Ride Bell
287	22" Jazz Ride
288	22" Jazz Ride Edge
289	22" Jazz Ride Bell
290	20" Rock Ride
291	20" Rock Ride Edge
292	20" Rock Ride Bell
293	808 Ride
294	Electronic Ride
295	Electronic Ride Edge
296	Electronic Ride Bell
297	20" Room Ride
298	20" Room Ride Edge
299	20" Room Ride Bell
300	HipHop Ride
301	20" Metal Ride

No.	Name
302	20" Metal Ride Edge
303	20" Metal Ride Bell
304	House Ride
305	House Ride Edge
306	House Ride Bell
307	Vintage Ride
308	Vintage Ride Edge
309	Vintage Ride Bell
310	Lo-Fi Ride
311	Lo-Fi Ride Edge
312	Lo-Fi Ride Bell
313	Techno Ride
314	Techno Ride Edge
315	Techno Ride Bell
<b>Crash</b>	
316	16" Acoustic Crash 1
317	16" Acoustic Crash 1 Edge
318	16" Acoustic Crash 2
319	16" Acoustic Crash 2 Edge
320	16" Standard Crash 1
321	16" Standard Crash 1 Edge
322	16" Standard Crash 2
323	16" Standard Crash 2 Edge
324	Brush Crash 1
325	Brush Crash 2
326	Brush Crash 3
327	Brush Crash 4
328	Funk Crash 1
329	Funk Crash 1 Edge
330	Funk Crash 2
331	Funk Crash 2 Edge
332	19" Jazz Crash 1
333	19" Jazz Crash 1 Edge
334	19" Jazz Crash 2
335	19" Jazz Crash 2 Edge
336	Rock Crash 1
337	Rock Crash 1 Edge
338	Rock Crash 2
339	Rock Crash 2 Edge
340	808Crash
341	909Crash 1
342	909Crash 2
343	Electronic Crash 1
344	Electronic Crash 2
345	Orchestra Crash 1
346	Orchestra Crash 2
347	Orchestra Crash 3
348	Room Crash
349	Room Crash Edge
350	1970's Crash 1
351	1970's Crash 2
352	Vintage Crash 1
353	Vintage Crash 1 Edge
354	Vintage Crash 2
355	Vintage Crash 2 Edge
356	Lo-Fi Crash 1
357	Lo-Fi Crash 1 Edge
358	Lo-Fi Crash 2
359	Lo-Fi Crash 2 Edge
360	Techno Crash 1
361	Techno Crash 1 Edge

## Voice List

No.	Name
362	Techno Crash 2
363	Techno Crash 2 Edge
364	Latin Crash 1
365	Latin Crash 1 Edge
366	Latin Crash 2
367	Latin Crash 2 Edge
368	China 1
369	China 1 Edge
370	Splash
371	Splash Edge
<b>HI-HAT</b>	
372	14" Acoustic Hi-hat
373	14" Acoustic Hi-hat Edge
374	14" Acoustic Hi-hat Pedal
375	14" Acoustic Hi-hat Splash
376	14" Standard Hi-hat
377	14" Standard Hi-hat Edge
378	14" Standard Hi-hat Pedal
379	14" Standard Hi-hat Splash
380	Brush Hi-hat
381	Brush Hi-hat Pedal
382	Brush Hi-hat Splash
383	14" Rock Hi-hat 1
384	14" Rock Hi-hat Edge 1
385	14" Rock Hi-hat Pedal 1
386	14" Rock Hi-hat Splash 1
387	14" Jazz Hi-hat
388	14" Jazz Hi-hat Edge
389	14" Jazz Hi-hat Pedal
390	14" Jazz Hi-hat Splash
391	14" Rock Hi-hat 2
392	14" Rock Hi-hat Edge 2
393	14" Rock Hi-hat Pedal 2
394	14" Rock Hi-hat Splash 2
395	808 Hi-hat
396	808 Hi-hat Pedal
397	808 Hi-hat Splash
398	909 Hi-hat
399	909 Hi-hat Pedal
400	909 Hi-hat Splash
401	Dance Hi-hat
402	Dance Hi-hat Pedal
403	Dance Hi-hat Splash
404	Lo-Fi Hi-hat
405	Lo-Fi Hi-hat Edge
406	Lo-Fi Hi-hat Pedal
407	Lo-Fi Hi-hat Splash
<b>Percussions</b>	
408	Maracas
409	Metronome Bell
410	Vibra-slap 1
411	Vibra-slap 2
412	Vibra-slap 3
413	Synthesis Percussion 1
414	Synthesis Percussion 2
415	High Q 1
416	High Q 2
417	Low Q 1
418	Low Q 2
419	Mute Hi Conga 1
420	Mute Hi Conga 2

No.	Name
421	Open Hi Conga 1
422	Open Hi Conga 2
423	Low Conga
424	High Bongo
425	Low Bongo
426	High Timbale 1
427	High Timbale 2
428	High Timbale 2 Rim
429	High Timbale 3
430	High Timbale 3 Rim
431	Low Timbale 1
432	Low Timbale 2
433	Low Timbale 2 Rim
434	Low Timbale 3
435	Low Timbale 4
436	High Agogo
437	Low Agogo
438	Claves
439	Jingle Bell
440	Cowbell
441	Bell Tree 1
442	Bell Tree 2
443	Tambourine
444	Cabasa
445	Long Guiro
446	Short Guiro
447	Indian 1
448	Indian 2
449	Indian 3
450	Indian 4
451	Indian 5
452	Indian 6
453	Indian 7
454	Indian 8
455	Indian 9
456	Indian 10
457	Indian 11
458	Indian 12
459	Indian 13
460	Indian 14
461	Indian 15
462	Indian 16
463	Indian 17
464	African 1
465	African 2
466	African 3
467	African 4
468	African 5
469	African 6
470	African 7
471	African 8
472	African 9
473	African 10
474	African 11
475	African 12
476	African 13
477	African 14
478	African 15
479	African 16
480	Marimba C3
481	Marimba A3

No.	Name
482	Marimba C4
483	Marimba Db4
484	Marimba D4
485	Marimba Eb4
486	Marimba E4
487	Marimba F4
488	Marimba Gb4
489	Marimba G4
490	Marimba Ab4
491	Marimba A4
492	Marimba Bb4
493	Marimba B4
494	Marimba C5
495	Marimba Db5
496	Marimba D5
497	Marimba Eb5
498	Marimba E5
499	Marimba F5
500	Marimba Gb5
501	Marimba G5
502	Marimba Ab5
503	Marimba A5
504	Marimba Bb5
505	Marimba B5
506	Marimba C6
507	Orchestra Timpani C2
508	Orchestra Timpani Db2
509	Orchestra Timpani D2
510	Orchestra Timpani Eb2
511	Orchestra Timpani E2
512	Orchestra Timpani F2
513	Orchestra Timpani Gb2
514	Orchestra Timpani G2
515	Orchestra Timpani Ab2
516	Orchestra Timpani A2
517	Orchestra Timpani Bb2
518	Orchestra Timpani B2
519	Orchestra Timpani C3
520	Orchestra Timpani Db3
521	Orchestra Timpani D3
522	Orchestra Timpani Eb3
523	Orchestra Timpani E3
524	Orchestra Timpani F3
525	Orchestra Timpani Gb3
526	Orchestra Timpani G3
527	Orchestra Timpani Ab3
528	Orchestra Timpani A3
529	Orchestra Timpani Bb3
530	Orchestra Timpani B3
531	Orchestra Timpani C4
<b>FX</b>	
532	FX 1
533	FX 2
534	FX 3
535	FX 4
536	FX 5
537	FX 6
538	FX 7
539	FX 8
540	FX 9
541	FX 10

## Voice List

No.	Name
542	FX 11
543	FX 12
544	FX 13
545	FX 14
546	FX 15
547	FX 16
548	FX 17
549	FX 18
550	Mute
HI-HAT Combination	
551	Acoustic
552	Funk Band
553	Standard
554	Jazz
555	Jazz Brush
556	Rock
557	808
558	909
559	Dance
560	Marimba
561	Indian
562	African
563	Lo-Fi