

User Manual

***Millenium***

BS-2222 Pro Set

Stand

Thomann GmbH  
Hans-Thomann-Straße 1  
96138 Burgebrach  
Germany  
Telephone: +49 (0) 9546 9223-0  
Internet: [www.thomann.de](http://www.thomann.de)

30.10.2023, ID: 267641 (V3)

---

## Table of contents

<b>1</b>	<b>General information.....</b>	<b>5</b>
	1.1 Symbols and signal words.....	5
<b>2</b>	<b>Safety instructions.....</b>	<b>7</b>
<b>3</b>	<b>Features.....</b>	<b>9</b>
<b>4</b>	<b>Operation.....</b>	<b>10</b>
<b>5</b>	<b>Technical specifications.....</b>	<b>14</b>
<b>6</b>	<b>Protecting the environment.....</b>	<b>16</b>




# 1 General information

This document contains important instructions for the safe operation of the product. Read and follow the safety instructions and all other instructions. Keep the document for future reference. Make sure that it is available to all those using the product. If you sell the product to another user, be sure that they also receive this document.

Our products and documentation are subject to a process of continuous development. They are therefore subject to change. Please refer to the latest version of the documentation, which is ready for download under [www.thomann.de](http://www.thomann.de).

## 1.1 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this document.

Signal word	Meaning
<b>DANGER!</b>	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
<b>CAUTION!</b>	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
<b>NOTICE!</b>	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – danger zone.

## 2 Safety instructions

### Intended use

This speaker stand is used for stable fixing and height-adjustable installation of loudspeaker cabinets. Use the product only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This product may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this product only if they are supervised or instructed by a person who is responsible for their safety.

### Safety



#### **DANGER!**

##### **Risk of injury and choking hazard for children!**

Children can suffocate on packaging material and small parts. Children can injure themselves when handling the product. Never allow children to play with the packaging material and the product. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the product without supervision. Keep small parts away from children and make sure that the product does not shed any small parts that children could play with.



#### **CAUTION!**

##### **Risk of injury due to tipping of the stand during loaded transport!**

If the stand is moved without having removed the installed devices, the stand may tip over and cause injuries and property damage. Remove the installed devices before transporting the stand.



**CAUTION!**

**Risk of injury due to tipping of stand on an unsuitable ground!**

When the stand is installed on soft or uneven ground, the stand may tip over and cause injuries and property damage. Install the stand only on even and solid ground.



**CAUTION!**

**Risk of injury due to tipping of the stand from excessive loading!**

In case of excessive loading, the stand might tip over, causing injury and property damage. Never exceed the specified maximum load for the stand.



**NOTICE!**

**Possible staining due to plasticiser in rubber feet!**

The plasticiser contained in the rubber feet of this product may react with the coating of the floor and cause permanent dark stains after some time. If necessary, use a suitable mat or felt slide to prevent direct contact between the device's rubber feet and the floor.



## 3 Features

Special characteristics:

- Professional steel speaker stand
- 2-pcs. set including carrying bag
- Extendible up to a height of about 2 m
- Centric load capacity up to 40 kg
- 35 mm pipe diameter at the pole mount
- Transport length when folded: 1.30 m

## 4 Operation

Unpack and check carefully there is no transportation damage before using the product. Keep the equipment packaging. To fully protect the product against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.



### **CAUTION!**

#### **Risk of injury due to tipping of the stand from excessive loading!**

In case of excessive loading, the stand might tip over, causing injury and property damage.

Never exceed the specified maximum load for the stand.



### **CAUTION!**

#### **Risk of injury due to tipping of stand on an unsuitable ground!**

When the stand is installed on soft or uneven ground, the stand may tip over and cause injuries and property damage.

Install the stand only on even and solid ground.



**CAUTION!**

**Risk of injury due to tipping of the stand during loaded transport!**

If the stand is moved without having removed the installed devices, the stand may tip over and cause injuries and property damage.

Remove the installed devices before transporting the stand.



***Comply with regulations***

*When installing and operating, make sure to follow the standards and regulations that apply in your country.*

### Setup



Follow the procedure described below for each of the two stands:

- 1.** ▶ Unfold the feet of the stand until the cross braces are in a horizontal position.
- 2.** ▶ Fix this position with the safety screw on the carriage to which the three feet are attached.
- 3.** ▶ fuse Press the locking lever and loosen the safety screw on the extension tube.
- 4.** ▶ Pull out the extension tube to the desired height and release the locking lever so that it can snap into the corresponding grid hole.
- 5.** ▶ Fix the position of the extension tube with the safety screw on the extension tube.
- 6.** ▶ Flange the speaker box to the top of the extension tube. The weight of the speaker box to be installed must not exceed the maximum centric load of 40 kg.

---

**Disassembly**

- 1.** ➤ Remove the speaker box.
- 2.** ➤ Press the locking lever while loosening the safety screw on the extension tube.
- 3.** ➤ Slide the extension tube all the way down and let the locking lever snap into the corresponding grid hole.
- 4.** ➤ Fix the position of the extension tube with the safety screw on the extension tube.
- 5.** ➤ Loosen the safety screw on the carriage to which the three feet are attached.
- 6.** ➤ Fold up the feet of the stand.

## 5 Technical specifications

Height, max.	2.00 m
Adjustable stand height	1.30 m ... 2.00 m
Stand tube diameter	Ø 35 mm
Mount type	Flange, Ø 35 mm
Load, max. (with centric load)	40 kg per stand
Transport length when folded	1.30 m
Weight	3.6 kg per stand
Colour	Black

**Further information**

Set of 2 stands	Yes
Material	Steel
Crank stand	No
Ringlock	No
Pneumatics	No
Foot type	Tripod

## 6 Protecting the environment

### Disposal of the packing material



Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner.

Do not dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the instructions and markings on the packaging.



Observe the disposal note regarding documentation in France.









