

### User manual

This manual contains important information on the safe operation of the device. Read and follow the safety advices and instructions given. Retain the manual for future reference. If you pass the device on to others please include this manual.

### Safety instructions

#### Intended use

This device is used to charge up to 12 transmitters / receivers of the device series 'Tour Guide Mini'. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

#### Danger for children



Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke! Never let unattended children use electrical devices.

#### Where to use the product

Never use the product

- in direct sunlight
- in conditions of extreme temperature or humidity

- in extremely dusty or dirty areas
- at locations where the unit can become wet
- near magnetic fields

#### Interference with other electrical equipment

Using the device near radios or TV sets may cause interference. Then increase the distance between the devices.

#### General handling

- To prevent damage, never use force when operating the switches and controls.
- Never immerse the appliance in water. Just wipe it with a clean dry cloth. Do not use liquid cleaners such as benzene, thinners or flammable cleaning agents.

#### Keep foreign substances from the unit!

Keep the device away from containers with liquids. Should any liquid get into the unit, this could lead to its destruction or fire. Be sure not to let any metal objects into the unit.

### Features

- 12 devices can be charged simultaneously
- Charging takes about 6 hours
- Mains power adapter included
- Nylon carrying bag (approx. 350 × 120 × 130 mm, black) included


### Operating elements




1. Device bay
2. Micro USB charging connector
3. Status LED

### Using the device

1. Connect the power adapter using the appropriate fitting piece for the operating location to a suitable wall outlet and connect the cable from the power adapter to the DC 5V port on the device.



2. Insert up to 12 transmitters / receivers of the device series 'Tour Guide Mini' so into the device bays that their micro USB port is aligned above the USB plug on the bottom of the bay.
3. Lightly press on the top of the devices so that the plug can get into the socket. Charging begins. A full recharge of the devices takes about 6 hours.
4. During charging, the status LED on the device bay lights red. When the device is fully charged, the LED lights green. If the LED is off, check the power supply.



### Technical specifications

Operating voltage mains adapter:

Primary: 100 V – 240 V~, 50 / 60 Hz

Secondary: 5 V =, 4 A

Number of device bays: 12

Format of charging plug: Micro USB



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.