



BT Receiver BT receiver



user manual

Musikhaus Thomann Thomann GmbH Hans-Thomann-Straße 1 96138 Burgebrach Germany Telephone: +49 (0) 9546 9223-0 E-mail: info@thomann.de Internet: www.thomann.de

29.11.2018, ID: 437452

Table of contents

1	General notes	. 4
	1.1 Further information	. 5
	1.2 Notational conventions	. 6
	1.3 Symbols and signal words	. 7
2	Safety instructions	. 9
3	Features	11
4	Installation and starting up	12
5	Connections and controls	14
6	Technical specifications	16
7	Plug and connection assignment	17
8	Protecting the environment	

th•mann

1 General notes

This manual contains important instructions for the safe operation of the unit. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the device. If you sell the unit please make sure that the buyer also receives this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change.



1.1 Further information

On our website (<u>www.thomann.de</u>) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search Use the search function in the electronic version to find the topics of interest for you quickly.	
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.



Letterings

1.2 Notational conventions

This manual uses the following notational conventions: The letterings for connectors and controls are marked by square brackets and italics. **Examples:** [VOLUME] control, [Mono] button.

DisplaysTexts and values displayed on the device are marked by quotation marks and italics.Examples: '24ch', 'OFF'.

Text inputText inputs that are carried out on the device are indicated by typewriter font.Example: 2323



Cross-references References to other locations in this manual are identified by an arrow and the specified page number. In the electronic version of the manual, you can click the cross-reference to jump to the specified location.

Example: See & 'Cross-references' on page 7.

1.3 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a pos- sible dangerous situation that can result in material and environmental damage if it is not avoided.

Warning signs	Type of danger
	Warning – danger zone.



2 Safety instructions

Intended use

This device is used to receive audio signals that are wirelessly transmitted via Bluetooth. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Safety



DANGER!

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.





NOTICE!

External power supply

The device is powered by an external power supply. Before connecting the external power supply, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly the user.

Unplug the external power supply before electrical storms occur and when the device is unused for long periods of time to reduce the risk of electric shock or fire.



NOTICE!

Operating conditions

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.

th•mann MUSIC IS OUR PASSION

3 Features

- Receiver for digital wireless transmission of audio signals via Bluetooth
- Outputs: 1/4" jack sockets (usable for balanced and unbalanced wiring)
- Plug-in power supply included
- Handy magnetic holder on the back

4 Installation and starting up

Unpack and carefully check that there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.

Create all connections while the device is off. Use the shortest possible high-quality cables for all connections. Take care when running the cables to prevent tripping hazards.



Pairing with Bluetooth devices

- **1.** Press the operating button.
 - \Rightarrow The light ring flashes quickly.
- **2.** The device is now visible to other Bluetooth devices under the name '*BT-4.0*' and can be paired.


If the other device is still working with a Bluetooth version older than 2.00, enter the password 0000 when prompted. For higher Bluetooth versions, no password is required.

⇒ After successful pairing, the light ring is lit continuously.

BT Receiver

th•mann

5 Connections and controls





1	[OUTPUT LEFT / RIGHT]		
	1/4" jack sockets for signal outputs		
2	Connector for the supplied plug-in power supply.		
3	[ANT]		
	Bluetooth signal antenna		
4, 5	Operating button with light ring		
	The light ring indicates the operating status of the device		
	Slow flashing: Standby		
	Fast flashing: Pairing with another Bluetooth device is running		
	Constant lighting: Connection to another Bluetooth device established		



thomann MUSIC IS OUR PASSION

6 Technical specifications

Voltage supply	Plug-in power supply (5 V / 2 A), positive pole via inner contact
Bluetooth version	V 4.0
Bluetooth protocol	HFP V1.6 wideband speech (HD voice ready); HSP V1.2; A2DP V1.2; AVRCP V1.4
Output level	Class2 4 dBm
Outdoor range	over 20 m
Input sensitivity	–80 dBm @ 0.1 % BER
Radio frequency range	2.4 GHz2.480 GHz
Signal-to-noise ratio	75 dB
THD	<0.01 %
Dimensions (W \times H \times D)	100 mm × 34 mm × 64 mm (15.35in. × 15.55in. × 5.31in.)
Weight	116 g



7 Plug and connection assignment

Introduction	This chapter will help you select the right cables and plugs to connect your valuable equip- ment in such a way that a perfect sound experience is ensured.	
	Please note these advices, because especially in 'Sound & Light' caution is indicated: Even if a plug fits into the socket, an incorrect connection may result in a destroyed power amp, a short circuit or 'just' in poor transmission quality!	
Balanced and unbalanced trans- mission	Unbalanced transmission is mainly used in semi-professional environment and in hifi use. Instrument cables with two conductors (one core plus shielding) are typical representatives of the unbalanced transmission. One conductor is ground and shielding while the signal is trans- mitted through the core.	
	Unbalanced transmission is susceptible to electromagnetic interference, especially at low levels, such as microphone signals and when using long cables.	
	In a professional environment, therefore, the balanced transmission is preferred, because this enables an undisturbed transmission of signals over long distances. In addition to the conduc- tors 'Ground' and 'Signal', in a balanced transmission a second core is added. This also transfers the signal, but phase-shifted by 180°.	

th.mann

Since the interference affects both cores equally, by subtracting the phase-shifted signals, the interfering signal is completely neutralized. The result is a pure signal without any noise interference.

1/4" TS phone plug (mono, unbalanced)



1	Signal
2	Ground, shielding

1/4" TRS phone plug (mono, balanced)

	1	Signal (in phase, +)
	2	Signal (out of phase, –)
NI CONTRACTOR	3	Ground



8 Protecting the environment

Disposal of the packaging material



Disposal of your old device



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.









Musikhaus Thomann • Hans-Thomann-Straße 1 • 96138 Burgebrach • Germany • www.thomann.de