

Pattern Overview

impression[&]
X4



from software version: 1.18/18/12/10/n
Rev. B




e-mail: service@glp.de
Internet: <http://www.glp.de>

1 Pattern

Patterns are grouped into two sets which can be activated and selected via the DMX channel "Special". Choose the desired pattern by its corresponding DMX value on channel "Pattern".

Orientation: Patterns are shown when looking at the **front** of a standing fixture; Head faced in direction of fixtures front label: DMX Pan @ 128; Tilt @ 220; Zoom @ 255 (letters are displayed homogenous).



Patterns Set 1

DMX	Pattern
000	
001	
002	
003	
004	
005	
006	
007	
008	
009	
010	
011	
012	

DMX	Pattern
013	
014	
015	
016	
017	
018	
019	
020	
021	
022	
023	
024	
025	

DMX	Pattern
026	
027	
028	
029	
030	
031	
032	
033	
034	
035	
036	
037	
038	

DMX	Pattern
039	
040	
041	
042	
043	
044	
045	
046	
047	
048	
049	
050	
051	

DMX	Pattern
052	
053	
054	
055	
056	
057	
058	
059	
060	
061	
062	
063	
064	
065	
066	
067	
068	

DMX	Pattern
069	
070	
071	
072	
073	
074	
075	
076	
077	
078	
079	
080	
081	
082	
083	
084	
085	

DMX	Pattern
086	
087	
088	
089	
090	
091	
092	
093	
094	
095	
096	
097	
098	
099	
100	
101	
102	

DMX	Pattern
103	
104	
105	
106	
107	
108	
109	
110	
111	
112	
113	
114	
115	
116	
117	
118	
119	

DMX	Pattern
120	
121	
122	
123	
124	
125	
126	
127	
128	
129	
130	
131	
132	
133	
134	
135	
136	

DMX	Pattern
137	
138	
139	
140	
141	
142	
143	
144	
145	
146	
147	
148	
149	
150	
151	
152	
153	

DMX	Pattern
154	
155	
156	
157	
158	
159	
160	
161	
162	
163	
164	
165	
166	
167	
168	
169	
170	

DMX	Pattern
171	
172	
173	
174	
175	
176	
177	
178	
179	
180	
181	
182	
183	
184	
185	
186	
187	

DMX	Pattern
188	
189	
190	
191	
192	
193	
194	
195	
196	
197	
198	
199	
200	
201	
202	
203	
204	

DMX	Pattern
205	
206	
207	
208	
209	
210	
211	
212	
213	
214	
215	
216	
217	
218	
219	
220	
221	

DMX	Pattern
222	
223	
224	
225	
226	
227	
228	
229	
230	
231	
232	
233	
234	
235	
236	
237	
238	

DMX	Pattern
239	
240	
241	
242	
243	
244	
245	
246	
247	
248	
249	
250	
251	
252	
253	reserved
254	reserved
255	reserved

Patterns Set 2

DMX	Pattern
000	
001	
002	
003	
004	
005	
006	
007	
008	
009	
010	
011	
012	
013	
014	
015	
016	

DMX	Pattern
017	
018	
019	
020	
021	
022	
023	
024	
025	
026	
027	
028	
029	
030	
031	
032	
033	

DMX	Pattern
034	
035	
036	
037	
038	
039	
040	
041	
042	
043	
044	
045	
046	
047	
048	
049	
050	

DMX	Pattern
051	
052	
053	
054	
055	
056	
057	
058	
059	-

