

- √ 5 isolated DC 9 V outputs à I20 mA
- √ AC 230 V supply voltage
- √ 30 mA current draw
- √ II6 x 77 x 38 mm (W × D × H)
- √ 920 g

## **Power Plant Junior**

**Compact 9 V power supply** 

This device offers 5 separate 9 V outputs and two sets of cables in different lengths. Each output delivers 120 mA. The power plant junior will keep your 9 V pedals performing quietly and powerfully. Moreover, it also comes with an extra Y-cable to supply pedals with a higher current draw as well as a serial cabel for powering up to 5 pedals from only one 9 V outlet. But make sure that the pedals connected to the serial cable do not require more than 24 mA each.



This device is meant to be used as a power supply unit for floor effect pedals within specifications given here. Use the device only as described here. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper useage.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this de-

vice only if they are supervised or instructed by a person who is responsible for their safety. Children must be supervised to ensure that they do not play with the device.

Within the device there are areas where high voltages may be present. Never remove any covers. There are no user-serviceable parts inside.

Do not modify the mains cable or the plug. Failure to do so could result in electric shock/death or fire.

Before connecting the device, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly injure the user.

Unplug the device before electrical storms occur and when it is unused for long periods of time to reduce the risk of electric shock or fire.

For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed and are not in the reach of babies and young children. Choking hazard! Do not just dispose these materials with your normal household waste, but make sure that they are fed to a recovery. Please follow the notes and markings on the packaging.



This device is subject to the European directive 2002/96/EC. Do not dispose the device with your normal household waste. Dispose this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

A detailed operating manual can be downloaded from www.thomann.de

Musikhaus Thomann e. K. Treppendorf 30 • 96138 Burgebrach Germany • www.thomann.de

