



- Padded shelf for mounting on a stand tube with a max. diameter of 20 mm
- Individual assembly thanks to adjustable crossbeam
  
- Material: steel
- Colour: black
- Load capacity: 3 kg
- Length of crossbeam: 190 mm
- Dimensions of support surface (W × D): 250 mm × 195 mm
- Weight: 1.22 kg


**General information**

This product is used as a stable stand for laptops. Read and follow the instructions. Keep the document for future reference. If you pass the product on to others, please include this document. Contents are subject to change. Please refer to the latest version of the documentation, which is available for download at [www.thomann.de](http://www.thomann.de).

**Intended use**

This product is used as a stable stand for laptops. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damage resulting from improper use. This product may be used only by persons with sufficient physical, sensory, and intellectual abilities and with the relevant knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.


**Risk of injury and choking hazard for children!**

Children can suffocate on packaging material and small parts. Children can injure themselves when handling the product. Never allow children to play with the packaging material and the product. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the product without supervision. Keep small parts away from children and make sure that the product does not shed any small parts that children could play with.


**Possible staining due to plasticiser in rubber pads!**

The plasticiser in the rubber pads of this product may react with other materials, resulting in permanent staining after a while. The product is not suitable for continuous use.


**Disposal of the packing material**

Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner. Do not dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the instructions and markings on the packaging.


**Disposal of your old product**

Do not dispose of your old product with your normal household waste; instead, deliver it for controlled disposal by an approved waste disposal firm or through your local waste facility.

Proper disposal protects the environment as well as the health of your fellow human beings. This is because the proper handling of old products negates the potential negative effects of hazardous substances, and because it conserves resources by recycling them.

Also note that waste avoidance is a valuable contribution to environmental protection. Repairing a device or passing it on to another user is an ecologically valuable alternative to disposal. For example, use the Thomann GmbH classified ads.



Observe the disposal note regarding documentation in France.