


## Features

- Suitable for Thomann Creative Desk 137 (Item no. 557673, 557666)
- Suitable for Thomann Creative Desk 159 (Item no. 573498, 573508)
- Can be mounted at 3 different heights
- Maximum load 20 kg
- Material:  
Chipboard, 25 mm, coated with melamine film  
Colour: Black (Item no. 557673, 573508)  
Colour: Anthracite (Item no. 557666, 573498)
- Overall dimensions (W × H × D):  
1238 mm × 400 mm × 25 mm (Item no. 557673, 557666)  
1458 mm × 400 mm × 25 mm (Item no. 573498, 573508)



Drawer rails







Table section – 2 pcs.




Drawer section – 2 pcs.


## Assembly material

- ①  M4x10 – 6 pcs.
- ②  3x20 – 6 pcs.


1.



2.



3.



**Risk of injury and choking hazard for children!**

Children can suffocate on packaging material and small parts. Children can injure themselves when handling the product. Never allow children to play with the packaging material and the product. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the product without supervision. Keep small parts away from children and make sure that the product does not shed any small parts that children could play with.



**Risk of injury due to the heavy weight of the product!**

The product is heavy. Lifting and dropping it during transport and installation can cause injuries. Make sure at least two people work together when transporting and installing the product.



**Possible staining due to plasticiser in rubber feet!**

The plasticiser contained in the rubber feet of this product may react with the coating of the floor and cause permanent dark stains after some time. If necessary, use a suitable mat or felt slide to prevent direct contact between the device's rubber feet and the floor.



Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the instructions and markings on the packaging.