EN

HDJ 3000



- Wired DJ Headphones
- Cable routed on one side
- Replaceable spiral cable
- Vegan artificial leather ear pads
- Adapter from 3.5 mm to 6.3 mm (included)
- Carrier bag (included)
- Colour: Black

Technical specifications

Design	Over-Ear, circumaural, closed, dynamic	
Driver	50 mm Ø	
Frequency range	20 Hz...20,000 Hz	
Mean sound pressure @1 mW, 1 kHz	99 dB ± 3 dB	
Sensitivity @1 kHz	99 dB ± 3 dB	
Impedance	32 Ω	
Rated load capacity	350 mW	
Max. load capacity	1,800 mW	
Cable length	1.5 m	
Connection	3.5 mm jack plug and 6.3 mm adapter	
Weight without cable	308 g	
Weight with cable	378 g	
Ambient conditions	Temperature range	0 °C to 40 °C
	Relative humidity (non-condensing)	20%...80%

Discover the entire t.bone range on our website:
tbone.audio

Visit us on Instagram and discover the full audio experience:
tbone.audio/instagram

Visit our YouTube channel for product videos and interesting stories:
tbone.audio/youtube

General information
This document contains important information. Read and follow the instructions. Keep the document for future reference. If you pass the product on to others, please include this document. Contents are subject to change. Please refer to the latest version of the documentation, which is ready for download under www.thomann.de.

Intended use
This device is designed to convert electrical signals into acoustic signals in the immediate vicinity of the ear. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damage resulting from improper use. This device may be used only by persons with sufficient physical, sensory, and intellectual abilities and the necessary knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Risk of injury and choking hazard for children!
Children can suffocate on packaging material and small parts. Children can injure themselves when handling the device. Never allow children to play with the packaging material and the device. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the device without supervision. Keep small parts away from children and make sure that the device does not shed any small parts (such as knobs) that children could play with.

Risk of death due to distraction!
Using headphones or earphones can distract your attention from your environment. Ambient noises may become inaudible in some cases. Do not use the device on the roads or while operating machinery.

Possible hearing damage due to high volumes on headphones!
The use of headphones at high volumes may result in permanent hearing impairment. Over an extended period of time, even levels that seem to be uncritical can cause hearing damage. Avoid operating headphones at high volumes, in particular over an extended period of time.

Disposal of the packing material
Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner. Do not dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the instructions and markings on the packaging.

Disposal of your old device
This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) as amended. Do not dispose of your old device with your normal household waste; instead, deliver it for controlled disposal by an approved waste disposal firm or through your local waste facility. If in doubt, consult your local waste management facility. You can also return the device to a retailer if they offer to take the device back for free or if they are legally obliged to do so. When disposing of the device, comply with the rules and regulations that apply in your country. You can also return your old device to Thomann GmbH at no charge. Check the current conditions at www.thomann.de. Proper disposal protects the environment as well as the health of your fellow human beings. This is because the proper handling of old devices negates the potential negative effects of hazardous substances, and because it conserves resources by recycling them. Also note that waste avoidance is a valuable contribution to environmental protection. Repairing a device or passing it on to another user is an ecologically valuable alternative to disposal. You can use the Thomann GmbH classified ads, for example. If your old device contains personal data, delete those data before disposing of it.

Observe the disposal note regarding documentation in France.