

- U-bracket for mounting an Achat 204 speaker



		204 WH U-Bracket horizontal (item no. 325273)	204 U-Bracket horizontal (item no. 269440)	204 U-Bracket vertical (item no. 269439)
Mounting		Horizontally on the ceiling or horizontally/vertically on the wall		Vertically on the ceiling or on a half-coupler
Dimensions (W × H × D)	Outside	60 mm × 380 mm × 155 mm		60 mm × 160 mm × 253 mm
	Inside	60 mm × 373 mm × 152 mm		60 mm × 155 mm × 250 mm
Material thickness		3 mm		3 mm
Holes	Bracket, long	2 × Ø 7 mm, 1 × Ø 13 mm		Ø 7 mm
	Bracket, short	3 × Ø 10 mm, 3 × Ø 7 mm		2 × Ø 7 mm, 1 × Ø 13 mm
Weight		0.8 kg		0.8 kg
Colour		White	Black	Black
Material		Steel (painted)		
Scope of delivery		1 × U-bracket, 1 × Allen screw (3/8-inch screw × 20 mm), 2 × rubber washer (Ø × H: 55 mm × 7 mm, hole: 10 mm)		1 × U-bracket, 2 × rubber washer, (Ø × H: 55 mm × 6 mm, hole: 11 mm)

General information

This document contains important information. Read and follow the instructions. Keep the document for future reference. If you pass the product on to others, please include this document. Contents are subject to change. Please refer to the latest version of the documentation, which is available for download at www.thomann.de.

Intended use

This product is used for the stable attachment of Achat speakers. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damage resulting from improper use. This product may be used only by persons with sufficient physical, sensory, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.



Risk of injury and choking hazard for children!

Children can suffocate on packaging material and small parts. Children can injure themselves when handling the product. Never allow children to play with the packaging material and the product. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the product without supervision. Keep small parts away from children and make sure that the product does not shed any small parts that children could play with.



Risk of injury due to improper installation!

Improper mounting can lead to serious injuries and significant damage to property. When installing and operating, make sure to follow the standards and regulations that apply in your country. In Germany, this is DGUV regulation 17 "Staging and Production Facilities for the Entertainment Industry". Ensure that speakers are only mounted by trained specialists.



Risk of injury from falling speakers that were inadequately secured!

If speakers are not properly secured when mounted, they can cause severe injury and considerable damage by falling. If speakers are mounted above head height, secure them with additional separate safety devices such as safety cables.



Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner. Do not dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the instructions and markings on the packaging.



Observe the disposal note regarding documentation in France.