



- Highly robust design
- Height-adjustable (max. 960 mm / min. 530 mm)
- Padded non-slip support
- Chrome-plated double-strut stand
- Desktop (W × H × D): 560 mm × 45 mm × 400 mm
- Transport dimension (W × H × L): 120 mm × 120 mm × 560 mm
- Max. centric load: 5 kg

General information

This document contains important information. Read and follow the instructions. Keep the document for future reference. If you pass the product on to others, please include this document. Contents are subject to change. Please refer to the latest version of the documentation, which is available for download at www.thomann.de.

Intended use

This product is designed as a support for percussion devices. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damage resulting from improper use. This device may be used only by persons with sufficient physical, sensory, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.



Risk of injury and choking hazard for children!

Children can suffocate on packaging material and small parts. Children can injure themselves when handling the product. Never allow children to play with the packaging material and the product. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the product without supervision. Keep small parts away from children and make sure that the product does not shed any small parts that children could play with.



Risk of injury due to tipping of the stand during transport under load!

If the stand is moved without removing the loaded equipment, the stand may tip over and cause injuries and property damage. Always remove equipment from the stand before moving the stand.



Risk of injury due to tipping, excessive loading and improper use!

In case of excessive and uneven loading, the product might tip over, causing injury and property damage. The product cannot hold people. Never sit on the product. Never exceed the specified maximum load for the product.



Risk of injury due to tipping of stand on an unsuitable ground!

If the stand is placed on soft or uneven ground, it may overturn and cause injuries and property damage. Place the stand only on flat and solid ground.



Possible staining due to plasticiser in rubber feet!

The plasticiser contained in the rubber feet of this product may react with the coating of the floor and cause permanent dark stains after some time. If necessary, use a suitable mat or felt slide to prevent direct contact between the device's rubber feet and the floor.



Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner. Do not dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the instructions and markings on the packaging.



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) as amended. Do not dispose of your old device with your normal household waste. Dispose of the product through an approved waste disposal firm or through your local waste management facility. When disposing of the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste management facility.