

Mixer Stand, Mixer Stand XL



- Multifunction stand for keyboards, mixers, speakers or cases
- Individually adjustable
- Leg length: 34.5 cm
- Frame diameter: 30 mm
- Middle brace:
650 mm (item no. 401521)
385 mm (item no. 378766)
- Height: 610 mm - 810 mm
- Width:
740 mm - 1,180 mm (item no. 401521)
430 mm - 660 mm (item no. 378766)
- Depth:
440 mm - 690 mm (item no. 401521)
350 mm - 440 mm (item no. 378766)
- Transport dimension (W × H):
740 mm × 625 mm (item no. 401521)
430 mm × 625 mm (item no. 378766)
- Material: Metal
- Weight:
7.5 kg (item no. 401521)
4.9 kg (item no. 378766)
- Max. load capacity: 60 kg

General information

This document contains important information. Read and follow the instructions. Keep the document for future reference. If you pass the product on to others, please include this document. Contents are subject to change. Please refer to the latest version of the documentation, which is available for download at www.thomann.de.

Intended use

This product is intended for stable fixing and height-adjustable installation of keyboards, speakers, mixers and cases. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damage resulting from improper use. This product may be used only by persons with sufficient physical, sensory, and intellectual abilities and with the relevant knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.



Risk of injury and choking hazard for children!

Children can suffocate on packaging material and small parts. Children can injure themselves when handling the product. Never allow children to play with the packaging material and the product. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the product without supervision. Keep small parts away from children and make sure that the product does not shed any small parts that children could play with.



Risk of injury due to tipping of the stand during transport under load!

If the stand is moved without removing the loaded equipment, the stand may tip over and cause injuries and property damage. Always remove equipment from the stand before moving the stand.



Risk of injury due to tipping of stand on unsuitable ground!

If the stand is placed on soft or uneven ground, it may tip over and cause injuries and property damage. Always set up the stand on level and firm ground.



Risk of injury due to tipping, excessive loading and improper use!

In case of excessive and uneven loading, the product might tip over, causing injury and property damage. The product cannot hold people. Never sit on the product. Never exceed the specified maximum load for the product.



Possible staining due to plasticiser in rubber feet!

The plasticiser contained in the rubber feet of this product may react with the coating of the floor and cause permanent dark stains after some time. If necessary, use a suitable mat or felt slide to prevent direct contact between the device's rubber feet and the floor.



Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner. Do not dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the instructions and markings on the packaging.



Observe the disposal note regarding documentation in France.