

Millenium

KS-1013 Slim Black



- Keyboard stand Economy especially for stage pianos
- Adjustable rubber supports at the bottom
- Double brace
- Quick release fastener (X stand)
- Maximum load up to 35 kg
- Tube depth: 26.2 cm
- Height adjustable from 62 cm (width then 80 cm) to 97 cm (width then 29 cm)
- Weight: 4 kg
- Colour: black



Intended use

This device is intended for use as stand for keyboard instruments. Any other use is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts from the product. They could swallow the pieces and choke! Never let children unattended use the product.

Danger of tipping on unsuitable ground

If placed on soft or uneven ground, the stand may overturn and cause injuries and property damage. Place the stand on flat and solid surfaces only.

Danger of tipping during loaded transport

If the stand is moved without removing the loaded equipment, the stand may tip over and cause injuries and property damage. Remove all equipment from the stand before moving the stand.



Danger of tipping due to overload

In case of overload, the stand may tip over and cause injuries and property damage. Never exceed the maximum load capacity specified for the stand.



Danger of pinching

When assembling the stand, pay attention not to squeeze your fingers/hands.



Possible staining

The plasticiser contained in the rubber feet of this product may possibly react with the coating of your surface and after some time cause permanent dark stains. In case of doubt, do not put the rubber feet directly on the surface and use a suitable underlay if necessary, i.e. felt-pad floor protectors or similar.



For the packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.