



The figures are designed for illustrative purposes.
The material depends on the product.

Wooden Rain Column 50

- Rain column with soothing rain sound
- Running time:
approx. 4 minutes – Wooden Rain Column 50OA4 (Artnr. 572619)
approx. 7 minutes – Wooden Rain Column 50OA7 (Artnr. 572620)
- Material: Oak
- Dimensions (H × Ø): 500 mm × 125 mm
- Weight:
approx. 2 kg – Wooden Rain Column 50OA4 (Artnr. 572619)
approx. 2.5 kg – Wooden Rain Column 50OA7 (Artnr. 572620)

Wooden Rain Column 55

- Rain column with soothing rain sound
- Running time: approx. 9 minutes
- Material:
Oak – Wooden Rain Column 55OA9 (Artnr. 572677)
- Dimensions (H × Ø): 550 mm × 125 mm
- Weight: approx. 2.9 kg

Wooden Rain Column 60

- Rain column with soothing rain sound
- Running time: approx. 12 minutes
- Material:
Oak – Wooden Rain Column 60OA (article no. 569178)
Ash – Wooden Rain Column 60AS (article no. 569179)
Elm – Wooden Rain Column 60EL (article no. 569180)
- Dimensions (H × Ø): 600 mm × 160 mm
- Weight: approx. 4 kg

Wooden Rain Column 100

- Rain column with soothing rain sound
- Running time: approx. 25 minutes
- Material:
Plum – Wooden Rain Column 100PL (article no. 569174)
Alder – Wooden Rain Column 100AL (article no. 569176)
Anigre – Wooden Rain Column 100AN (article no. 569177)
- Dimensions (H × Ø): 1,000 mm × 160 mm
- Weight: approx. 7 kg

Wooden Rain Column 150

- Rain column with soothing rain sound
- Running time: approx. 60 minutes
- Material:
Walnut – Wooden Rain Column 150WN (article no. 569173)
- Dimensions (H × Ø): 1,000 mm × 160 mm
- Weight: approx. 13 kg

Before first use

During transport, the mixture of amaranth and small glass beads inside the rain column enters the play area.

As a result, the rain column may not work properly.

To reset the rain column, place it on one of the two cork surfaces and allow the mixture to run into the bottom funnel until the sound stops.

Then shake the rain column gently until you hear a sound again. Repeat this process at least five times.

Once the sound has stopped, gently shake the rain column again and then turn it over. The mixture will now run through the rain column from the upper funnel over the specified running time.

Intended use

This product serves as an effect instrument. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damage resulting from improper use.



Risk of injury and choking hazard for children!

Children can suffocate on packaging material and small parts. Children can injure themselves when handling the product. Never allow children to play with the packaging material and the product. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the product without supervision. Keep small parts away from children and make sure that the product does not shed any small parts that children could play with.



Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the instructions and markings on the packaging.