

## Software-Update

To carry out a software update of the drum module, you can download the latest software from our homepage ([www.thomann.de](http://www.thomann.de)). The software is only suitable for a Microsoft Windows operating system.

1. Download the software update **HD\_Drum\_Code\_upgrade**.



2. Unzip the compressed file with an unzipper.
3. Hold down [▼] and switch on the drum module.  
→ The display shows 'UPG'.



4. Connect your computer to the USB MIDI port [USB] of the drum module.

NOTE:


When connecting your computer to the drum module for the first time, the driver is automatically installed on your computer. Wait until the installation is complete before proceeding.

5. Double-click the software update **HD\_Drum\_Code\_upgrader**.

→ The dialogue window 'Code Upgrader V2.0' opens.



6. Click the [Upgrade] button in the dialog box and confirm your selection with [Yes].



→ The update process starts. The status is shown in the progress bar.



7. After a successful software update a reset to factory settings of the drum module is necessary. Click the [OK] button in the dialogue window.



8. Disconnect the drum module from your computer and turn the drum module off. Press and hold [♭] and [▲] simultaneously.

→ The display shows 'CLR'. The drum module is reset to factory settings and is ready for use again.