Sound Module Update Guide

1. Connect the sound module to computer via USB cable (USB B type to USB A type), press and hold both [+][-] buttons and then power on the module to enter upgrade mode.
2. Please kindly noted that for **MPS-750** & **MPS-750X**, bootloader version shown in upgrade mode must be higher than 4.00.


3. Run Firmware Upgrade Tool.
4. Click [Refresh], and select **E-DRUM** or **USB A** for both Input & Output device.

5. Drag& drop the upgrade file anywhere in the window.
6. Click [Start]

7. Make sure the device is in Upgrade Mode. Then click [OK]

8. Wait the progress bar until it shows a completion dialogue.

9. Turn off the sound module by pressing power button.
10. To check firmware version:
    a) **MPS750 & MPS-750X:**
        i. Power on the device.
        ii. When you see 'Initializing…', press and hold both [+] and [-] until the display changes to all white.
        iii. Version number will be shown on the top-left corner, such as V4.xx.
        Then number shown in upgrade mode is the version of bootloader. It is not the same as firmware.
    b) **MPS-1000:**
        All version numbers are shown in upgrade mode.