

INSPECTION

1. Unpack and inspect the MM11 package. Your MM11 was carefully packed at the factory in a protective carton. Nonetheless, be sure to examine the unit and the carton for any signs of damage that may have occurred during shipping. If obvious physical damage is noticed, contact the carrier immediately to make a damage claim. We suggest saving the shipping carton and packing materials for safely transporting the unit in the future.

2. For warranty registration go to our website: WWW.ROLLS.COM

MM11 MicMute

- Male and Female XLR jacks
- Momentary Mute Switch
- Rear panel screw holes for convenient mounting

This simple device momentarily mutes a microphone signal. This function is very handy in the event of a sneeze, cough, or other possible distracting noise.

MM11 MicMute



ROLLS

Rolls Corporation
Salt Lake City, UT
5/12

ROLLS

MM11 MicMute



Thank you for your purchase of the MM11 MicMute microphone muting switch. This simple device momentarily mutes a microphone signal. This function is very handy in the event of a sneeze, cough, or other possible distracting noise.



The MM11 rear panel has two screw holes for convenient mounting to the Rolls MSC106 Mic Stand Clamp.

To register the warranty for this product, visit our website at www.rolls.com and click on the "Register Your Warranty Here" text, or fill out the warranty card and return it to the factory.

DESCRIPTION

The MM11 consists of two balanced XLR jacks; one female Input, one male Output, and a momentary touch switch.

OPERATION

To mute a microphone signal, connect the balanced cable to the microphone, and to the female input jack on the MM11. Connect the male output jack to another cable, and its end to your next device.

Press and hold the switch for the amount of time you want the signal muted. To hear the signal again, release the switch.

Quick Start Guide