Thank you for your purchase of the Rolls DU30b Mic Preamp Audio Ducker. This device temporarily and automatically mutes or "ducks" a background music signal under a paging microphone or other auxiliary signal. After the announcement, the music level is automatically returned to it's previous level.

#### **DESCRIPTION**

## **REAR PANEL**

MIC IN: Female XLR jack for connection to a dynamic or condenser paging microphone.

PHTM PWR: Jumper for engaging the +12 volt phantom power to the microphone input - configured OFF from the factory.

AUX IN: Stereo RCA jacks for connecting to a source different from the Mic In as the master signal.

LINE IN: Stereo RCA jack for connection to the stereo signal source to be "ducked" such as a tuner, CD player or cassette player.

OUTPUT: Stereo RCA jacks for connection to the system's amplifiers.

12 VDC: Power input. Connect to the enclosed Rolls PS27 AC adapter.

### **FRONT PANEL**

MIC/LINE: When pressed in, the gain of the XLR Mic In is reduced by 30 dB.

RELEASE TIME: Adjusts the amount of time for the "ducked" signal to return to its normal level. Counterclockwise; slow - Clockwise; fast.





MIC LEVEL: Adjusts the amount of gain in the Mic In circuit. DUCK SENSITIVITY: The Threshold at which "ducking" begins. When the microphone level reaches the threshold, the signal present at the Line In jacks is reduced until the announcement is over, then the Line In signal returns to its previous level

A NOTE ON THE DU30b THRESHOLD SETTING, WITH THE SENSITIVITY CONTROL FULLY CLOCKWISE: If the control (paging) signal is on the XLR input, then ducking begins (the threshold is) at -40 dB when the Mic/Line switch is set to "Mic", and 0 dB when the switch is set to "Line". If the control signal is on the RCA input, ducking begins at -40 dB. DUCK DEPTH: Adjusts the amount of background signal (or Line In) reduction - fully counter clockwise the signal is reduced 6 dB, fully clockwise the signal is reduced 70 dB.

## **OPERATION**

If you are using a condenser microphone, carefully connect the two Phantom Power jumper pins together. Set the level of the music signal (Line In) for a comfortable level. Speak into the microphone and adjust the Mic Level for a comfortable level, then adjust the Sensitivity so that the music is muted when speaking with a normal voice. Set the Release Time control for the amount of time you wish for the Aux In signal to return to normal. Set the Duck Depth control for the amount of Aux In signal reduction you want when the Mic or Alternate signal is present.

## WARRANTY

For information on the Rolls One Year Limited Warranty, and to register this product, visit our website at <a href="www.rolls.com">www.rolls.com</a>

# **DU30b DUCKER**

- Automatically ducks music under announcements
- Perfect for restaurants and small clubs
- Clean, Quiet Mic Preamp

The DU30b is a microphone preamp and background music preamp. When an announcement is made into the microphone, the music is automatically "ducked" under the announcement. Then the music is brought back to it's previous level.

## **SPECIFICATIONS**

Frequency Response 20 Hz - 40 kHz

Input Impedance 100K $\Omega$  unbalanced, 600  $\Omega$  balanced

THD + Noise <0.03% typical

Noise Floor -78 dB Indicators Power LED

Input/Output jacks XLR balanced output

RCA unbalanced input and output

Size: 4" x 4" x 1.5"

Weight: 1 lb. (.5 kg)

Power: 12 - 16 VDC 50mA

5 x 1.2 mm DC Jack - Center Negative





