

Quick start guide

This document contains important information on the safe use of the product. Read and follow the safety instructions and all other instructions. Keep the document for future reference. If you pass the product on to others, please include this

Contents are subject to change. Please refer to the latest version of the documentation, which is available for download at www.thomann.de.

Safety instructions

Intended use

This device is intended for the temporary illumination of racks by means of LED technology. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damage resulting from improper use.

This device may be used only by persons with sufficient physical, sensory, and intellectual abilities and the necessary knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.



Extend the operating life of the device by means of regular pauses in operation and by avoiding frequent switching on and off. The device is not suitable for continuous operation.

Risk of injury and choking hazard for children!



Children can suffocate on packaging material and small parts. Children can injure themselves when handling the device. Never allow children to play with the packaging material and the device. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the device without supervision. Keep small parts away from children and make sure that the device does not shed any small parts (such as knobs) that children could play with.

Risk of death from electrical current!



The device contains parts where high voltage is present. Never remove any covers! There are no user-serviceable parts inside the device. Do not use the device if covers, safety equipment or optical components are missing or damaged.

Risk of death from electrical current!



A short circuit can cause fires and loss of life. Always use a properly insulated two-core mains cable. Do not modify the mains cable or the power plug. If the insulation is damaged, immediately switch off the power supply and have it repaired. If in doubt, contact a qualified electrician.

Risk of eye damage caused by high light intensity!



The device generates high-intensity light radiation. Looking directly into the light source can damage the eyes. Never look directly into the light

Risk of fire due to covered vents and neighbouring heat sources!



If the vents of the device are covered or the device is operated in the immediate vicinity of other heat sources, the device can overheat and burst into flames. Never cover the device or the vents. Do not install the device in the immediate vicinity of other heat sources. Never operate the device in the immediate vicinity of naked flames.

Damage to the device if operated in unsuitable ambient conditions!



The device can be damaged if it is operated in unsuitable ambient conditions. Only operate the device indoors within the ambient conditions specified in the "Technical specifications". Avoid operating it in environments with direct sunlight, heavy dirt and strong vibrations. Avoid operating it in environments with strong temperature fluctuations. If temperature fluctuations cannot be avoided (for example after transport in low outside temperatures), do not switch on the device immediately. Never subject the device to liquids or moisture. Never move the device to another location while it is in operation. In environments with increased dirt levels (for example due to dust, smoke, nicotine or mist): Have the device cleaned by qualified specialists at regular intervals to prevent damage due to overheating and other malfunctions.

Damage to the external power supply due to high voltages!



The device is powered by an external power supply. The external power supply can be damaged if it is operated with the incorrect voltage or if high voltage peaks occur. In the worst case, excess voltages can also cause a risk of injury and fires. Make sure that the voltage specification on the external power supply matches the local power grid before plugging in the power supply. Only operate the external power supply from professionally installed mains sockets that are protected by a residual current circuit breaker (FI). Ensure that the power cord plug is easily accessible at all times if it is the only device to safely disconnect the device from the mains supply. As a precaution, disconnect the power supply from the power grid when storms are approaching or if the device will not be used for a longer period.

General handling

- To prevent damage, never exert force while operating the device.
- Never immerse the device in water. Wipe only with a clean and dry cloth. Do not use liquid cleaners such as benzene, thinners or flammable cleaning agents
- For technological reasons, the light output of LEDs decreases over their lifetime. This effect increases with higher operating temperatures. You can extend the service life of the light sources by providing adequate ventilation and operating the LEDs with the lowest possible brightness.

Keep foreign substances away from the device!

Keep the device away containers with liquid. Should liquid enter the device, this could lead to its destruction or fire. Ensure that no metallic parts enter the device.

Features

- · Multicolour rack light for even illumination of the rack
- 19" rack-mountable (1 RU)
- 15 selectable macros with different shades of colour and white
- · Three selectable brightness levels

- · Memory function
- Sturdy metal design
- · Including power adapter
- · Strain relief for the power adapter



Connections and controls



- [Dimmer/Switch] | Button for turning the device on and off and for adjusting the brightness of the LEDs
- 2 [POWER IN] | Connecting socket for the power adapter
- [Colors] | Button for adjusting the colour of the LEDs

Operation

Turning the device on and off

1. Press and hold [Dimmer/Switch] to turn the device on or off.

Setting the brightness

Press [Dimmer/Switch] repeatedly to select one of the three brightness levels of the LEDs.

Macros setting

1. Press [Colors] repeatedly to select one of the 15 colours and whites of the LEDs.

1. Brightness and macro settings are retained even when the device is disconnected from the mains.

Technical specifications

30 × RGBW 4in1 LED Light source Mounting options

150 lumen Material Light source properties Light output Metal Control Buttons on the unit Colour Black

Input connections Power supply Socket for power adapter Dimensions (W \times H \times D) $485 \text{ mm} \times 44 \text{ mm} \times 60 \text{ mm}$

0.9 kg external power adapter, Power supply Weiaht

100 - 240 V~ 50/60 Hz Ambient conditions 0 °C...40 °C Temperature range 12 V — 1 A Operating voltage Relative humidity 20%...80% centre positive

(non-condensing)

Rack mounting, 1 RU



Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner. Do not dispose of these materials with $your \, normal \, household \, waste, but \, make \, sure \, that \, they \, are \, collected \, for \, recycling.$ Please follow the instructions and markings on the packaging.



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) as amended.

Do not dispose of your old device with your normal household waste; instead, deliver it for controlled disposal by an approved waste disposal firm or through your local waste facility. If in doubt, consult your local waste management facility. You can also return the device to a retailer if they offer to take the device back for free or if they are legally obliged to do so. When disposing of the device, comply with the rules and regulations that apply in your country. You can also return your old device to Thomann GmbH at no charge. Check the current conditions on www.thomann.de. Proper disposal protects the environment as well as the health of your fellow human beings. This is because the proper handling of old devices negates the potential negative effects of hazardous substances, and because it conserves resources by recycling them. Also note that waste avoidance is a valuable contribution to environmental protection. Repairing a device or passing it on to another user is an ecologically valuable alternative to disposal. For example, use the Thomann GmbH classified ads.

If your old device contains personal data, delete those data before disposing of it. Observe the disposal note regarding documentation in France.