


Startone★

MKR 61

roll-up keyboard



Musikhaus Thomann
Thomann GmbH
Hans-Thomann-Straße 1
96138 Burgebrach
Germany
Telephone: +49 (0) 9546 9223-0
E-mail: info@thomann.de
Internet: www.thomann.de

12.03.2021, ID: 353537 (V4)

Table of contents

1	General information	4
	1.1 Further information.....	5
	1.2 Notational conventions.....	6
	1.3 Symbols and signal words.....	7
2	Safety instructions	9
3	Features	12
4	Installation	13
	4.1 Dealing with lithium batteries.....	14
5	Control panel and connections	16
6	Technical specifications	25
7	Protecting the environment	28

1 General information

This user manual contains important information on the safe operation of the device. Read and follow all safety notes and all instructions. Save this manual for future reference. Make sure that it is available to all persons using this device. If you sell the device to another user, be sure that they also receive this manual.

Our products and user manuals are subject to a process of continuous development. We therefore reserve the right to make changes without notice. Please refer to the latest version of the user manual which is ready for download under www.thomann.de.

1.1 Further information

On our website (www.thomann.de) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.

1.2 Notational conventions

This manual uses the following notational conventions:

Letterings

The letterings for connectors and controls are marked by square brackets and italics.

Examples: *[VOLUME]* control, *[Mono]* button.

Displays

Texts and values displayed on the device are marked by quotation marks and italics.

Examples: *'24ch'*, *'OFF'*.

Cross-references

References to other locations in this manual are identified by an arrow and the specified page number. In the electronic version of the manual, you can click the cross-reference to jump to the specified location.

Example: See ↗ *'Cross-references'* on page 6.

1.3 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
WARNING!	This combination of symbol and signal word indicates a possible dangerous situation that can result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.

Warning signs	Type of danger
	Warning – danger zone.

2 Safety instructions

Intended use

This device is intended to be used for electronic sound generation using a piano keyboard. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Safety



DANGER!

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke! Never let children unattended use electrical devices.



WARNING!

Incorrect handling of lithium batteries can result in injury

In the event of a short circuit, overheating or mechanical damage, lithium batteries can cause severe injuries. Follow the advice on the correct handling of lithium batteries in the present section.



CAUTION!

Possible hearing damage

With loudspeakers or headphones connected, the device can produce volume levels that may cause temporary or permanent hearing impairment. Do not operate the device permanently at a high volume level. Decrease the volume level immediately if you experience ringing in your ears or hearing impairment.



NOTICE!

Possible damage by leaking batteries

Leaking batteries can cause permanent damage to the device. Take batteries out of the device if it is not going to be used for a longer period.



NOTICE!

Operating conditions

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations. Only operate the device within the ambient conditions specified in the chapter 'Technical specifications' of this user manual. Avoid heavy temperature fluctuations and do not switch the device on immediately after it was exposed to temperature fluctuations (for example after transport at low outside temperatures). Dust and dirt inside can damage the unit. When operated in harmful ambient conditions (dust, smoke, nicotine, fog, etc.), the unit should be maintained by qualified service personnel at regular intervals to prevent overheating and other malfunction.



NOTICE!

Possible damage to lithium-ion batteries through incorrect storage

By deep discharge, lithium-ion batteries can be permanently damaged or lose some of their capacity. Before long breaks, charge the batteries to around 50 % of their capacity and then switch off the device. Store the device at room temperature or cooler in an environment as dry as possible. If the batteries are stored for a longer period, recharge them to 50 % every three months. Fully charge the batteries only shortly before use at room temperature.

3 Features

The Roll-up keyboard is characterized by the following features:

- 61 keys
- 128 preprogrammed sounds
- 128 preprogrammed styles
- 45 demo songs
- Record and playback function
- Single-finger and multi-finger operation
- Sustain
- Vibrato
- Digital display
- Built-in speakers
- Connections: Headphones out, USB charger connection, MIDI out, audio in

4 Installation

The device is powered by a rechargeable lithium-ion battery. Use only the included lithium-ion battery or a spare battery with identical specifications (see [Chapter 6 'Technical specifications'](#) on page 25).

Use the included USB charging cable for charging the inserted battery. Connect the device to the USB port of a PC for charging via this cable.

After playing the Silicone keyboard, roll it up loosely and keep the unit in its original packaging. Do not kink the Silicone keyboard.

The unit automatically switches to standby mode when you don't press any key for about 5 minutes. To reactivate the device into normal operating mode press any key of the keyboard.

4.1 Dealing with lithium batteries



WARNING!

Incorrect handling of lithium batteries can result in injury

In the event of a short circuit, overheating or mechanical damage, lithium batteries can cause severe injuries.

Follow the advice on the correct handling of lithium batteries in the present section.

When handled correctly and appropriately lithium batteries pose no risk.

Store lithium batteries in a cool, dry place, ideally in the original packaging.

Store lithium batteries away from heat sources (e.g. radiators or sunlight). Lithium batteries are hermetically sealed. Never attempt to open a lithium battery.

If the battery housing is damaged small amounts of the electrolyte may leak out. If this should happen, seal the lithium battery in airtight packaging and wipe up the traces of electrolyte using absorbent paper towels. You must wear protective rubber gloves when doing so. Clean your hands and the affected surface thoroughly with cold water.


Never attempt to recharge non-rechargeable lithium batteries. When charging lithium batteries you must use a suitable charging device intended for the purpose.

Before disposing of the device remove the lithium batteries. Protect used lithium batteries against potential short circuits, e.g. by covering the poles with adhesive tape.

Only use powder extinguishers or other suitable extinguishing agents to extinguish a burning lithium battery.

5 Control panel and connections

Operating panel



1	Keyboard.
2	Speaker.
3	Display.
4	[+] Increases the displayed value by one.
5	[Tone] Button to select a preprogrammed sound. Press the button to activate the selection. The display shows 'tnE'. Use the buttons [+] and [-] to select a sound setting in the range of '000' ... '127'.
6	[OOP] Button to activate the 'OOP' mode. In this mode, you can record your own short drum sequences of up to 32 individual drum hits. Press the ► button to play your recording. The sequence is repeated in a continuous loop until you press the ► button. If you press the button [OOP] again and start a new recording, the previous sequence will be overwritten.

7 *[Drum Kit]*

Button to activate the 'Drum Kit' mode.

In this mode you create drum sounds using the various keys, (bass drum, snare, hi-hat, cymbals and effects).

Press the button once to activate the mode. The display briefly shows 'On'.

Press the button again to exit the mode. The display briefly shows 'OFF'.

8 *[Sustain]*

Button to activate the Sustain effect.

Press the button once to activate the effect. The display shows 'SUS'.

Press the button again to deactivate the effect. The display briefly shows 'OFF'.

9 *[Vibrato]*

Button to activate the Vibrato effect.

Press the button once to activate the effect. The display shows 'Vib'.

Press the button again to deactivate the effect. The display briefly shows 'OFF'.

10	<i>[Vol]</i> Buttons for increasing / decreasing the volume. Press the keys briefly to gradually adjust the setting. Keep the buttons pressed to adjust the setting quickly up and down.
11	▶ Playback button. Starts and stops playback of user recordings in recording mode.
12	▶ Play / Pause button. Press the button once to start playback of styles and demo pieces. Press the button again to stop playback of styles and demo pieces.
13	<i>[Insert]</i> Button to insert a fill when playing styles. Press the button once to insert a fill at the end of the currently playing bar.

14	<p><i>[OKON]</i></p> <p>Button to activate the Learn mode.</p> <p>Press the button once to activate the Learn mode. The display shows 'LEn'. Then start the playback of the various demo pieces with the keys of the keyboard. You have now the option to accompany the playing song.</p> <p>You can pause the playback with ► .</p> <p>Press the button <i>[OKON]</i> again to exit the mode. The display briefly shows 'OFF'.</p>
15	<p>Battery charging indicator</p> <p>This LED lights red during charging. Once the installed battery pack is fully charged, the LED turns green. In normal operation, the LED is off.</p>
16	<p>Power indicator</p> <p>This LED lights constantly red during operating.</p>
17	<p><i>[-]</i></p> <p>Decreases the displayed value by one.</p>

18 [RHY]

Button to select a preprogrammed style.

Press the button to activate the selection. The display shows 'rhy'. Use the buttons [+] and [-] to select a style in the range of '000' ... '127'.

19 [REC]

Button to activate the 'recording' mode (display shows 'LEn').

In this mode, you can record your own sequences of up to 92 notes. Press the ► button to play your recording. The sequence is being played until you press the ►|| button (display shows 'OFF').

If you press the button [REC] again and start a recording, the previous sequence will be overwritten.

20 [Demo]


Button to activate the 'Demo' mode.

Press the button to activate the selection. The display shows 'd00' and the first demo track will be played immediately. Use the buttons [+] and [-] to switch at will between the preprogrammed demo pieces 'd00' ... 'd44'.

Press the Play / Pause button to stop the playback of demo pieces.

21	<p><i>[Single]</i></p> <p>Button to activate the single-finger mode when playing a preprogrammed style (display shows 'Sin').</p> <p>Press the Playback / Pause button to start style playback or press the button <i>[Single]</i> or the Playback button along with a key in the range of C3 ... F4#. Then the keyboard automatically plays an appropriate accompaniment.</p>
22	<p><i>[Finger]</i></p> <p>Button to activate the multi-finger mode when playing a preprogrammed style (display shows 'Fin').</p> <p>Press the Playback / Pause button to start style playback or press the button <i>[Finger]</i> along with multiple keys in the range of C3 ... F4#. Then the keyboard automatically plays an appropriate accompaniment.</p>
23	<p><i>[Temp]</i></p> <p>Buttons to increase / decrease the playback speed of sounds, styles and demo pieces in the range of '030' ... '240'.</p> <p>Press the keys briefly to gradually adjust the setting. Keep the buttons pressed to adjust the setting quickly up and down.</p>

Connections



24 [OFF | ON]

Main switch to turn the device on and off.

25 [AUDIO INPUT]

Input socket for connecting an external audio device (e.g. MP3 or CD player).

26 [HEADPHONE]

Output for headphones or external audio devices like active speakers or amplifiers.

27 *[POWER | MIDI OUT]*

Connection for the supplied USB cable to charge the installed battery pack via the USB port of a computer and for transferring MIDI data.

28 *[USB CHARGING]*

USB charger connection.

Battery compartment

The battery compartment is located on the back of the control panel.

6 Technical specifications

Input connections	USB	USB charger connection
	Audio signal	3.5 mm phone socket
Output connections	Headphones	3.5 mm phone socket
	MIDI port	USB
Keyboard	Rollable silicone keyboard with 61 keys	
Sounds	128	
Styles	128	
Demo and practice songs	45	
Battery	Battery type	Lithium-ion
	Voltage	3.7 V
	Capacity	1000 mAh
Dimensions operating panel (W × H × D)	110 mm × 215 mm × 35 mm	

Technical specifications

Dimensions keyboard (W × H × D)	900 mm × 166 mm × 8 mm	
Weight	986 g	
Ambient conditions	Temperature range	0 °C...40 °C
	Relative humidity	20 %...80 % (non-condensing)

Further information

Buttons	61
Illuminated keys	No
Touch velocity	No
Aftertouch	No
Storage device	None
Lyrics function	No
Score function	No
Vocal Harmony	No
USB audio recorder	No
MIDI port	None
Microphone connection	No
USB	Yes

7 Protecting the environment

Disposal of the packaging material



For the packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

Disposal of batteries



Batteries do contain some hazardous chemicals so they should not be thrown away with the normal household waste. They should be returned to the manufacturer for disposal or recycled elsewhere in accordance with your local regulations.

Dispose lithium batteries only in discharged condition. Remove lithium batteries from the device before disposal. Protect used lithium batteries against potential short circuits, e.g. by covering the poles with adhesive tape. Dispose the built-in lithium batteries together with the device. Please check for an appropriate reception facility.

Disposal of your old device



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.



