

Harley Benton

Mighty-5TH guitar amp head

Musikhaus Thomann

Thomann GmbH

Hans-Thomann-Straße 1

96138 Burgebrach

Germany

Telephone: +49 (0) 9546 9223-0

E-mail: info@thomann.de

Internet: www.thomann.de

07.10.2020, ID: 420283

## **Table of contents**

1	General information	
	1.1 Further information	
	1.2 Notational conventions	
	1.3 Symbols and signal words	
2	Safety instructions	
3	Features	
4	Installation and starting up 1	
5	Connections and controls	
6	Technical specifications	
7	Plug and connection assignment 1	
8	Cleaning	
9	Protecting the environment	



## 1 General information

This manual contains important instructions for the safe operation of the unit. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the device. If you sell the unit please make sure that the buyer also receives this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change.



## 1.1 Further information

On our website (<u>www.thomann.de</u>) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation For personal consultation please contact our technical hotline.	
Service	If you have any problems with the device the customer service will gladly assist you.



### 1.2 Notational conventions

This manual uses the following notational conventions:

Letterings

The letterings for connectors and controls are marked by square brackets and italics.

**Examples:** [VOLUME] control, [Mono] button.

## 1.3 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.



Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
A	Warning – high-voltage.
<u>^</u>	Warning – danger zone.



## 2 Safety instructions

#### Intended use

This device is intended to be used for the amplification of signals from musical instruments with electromagnetic pickups. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.



### Safety



#### DANGER!

### **Danger for children**

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.



#### **DANGER!**

### Electric shock caused by high voltages inside

Within the device there are areas where high voltages may be present. Never remove any covers.

There are no user-serviceable parts inside.

Do not use the device if covers, protectors or optical components are missing or damaged.





#### **DANGER!**

## **Electric shock caused by short-circuit**

Always use proper ready-made insulated mains cabling (power cord) with a protective contact plug. Do not modify the mains cable or the plug. Failure to do so could result in electric shock/death or fire. If in doubt, seek advice from a registered electrician.



#### **CAUTION!**

## Possible hearing damage

With loudspeakers connected, the device can produce volume levels that may cause temporary or permanent hearing impairment. Over an extended period of time, even levels that seem to be uncritical can cause hearing damage.

Do not operate the device permanently at a high volume level. Decrease the volume level immediately if you experience ringing in your ears or hearing impairment. If this is not possible, keep a bigger distance to the speaker or use sufficient ear protectors.





#### NOTICE!

#### Risk of fire

Do not block areas of ventilation. Do not install the device near any direct heat source. Keep the device away from naked flames.



#### NOTICE!

## **Operating conditions**

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.





#### NOTICE!

## **Power supply**

Before connecting the device, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly injure the user.

Unplug the device before electrical storms occur and when it is unused for long periods of time to reduce the risk of electric shock or fire.



## 3 Features

- Tube amp head for electric guitar
- Class A circuit
- Built-in power soak for 1 W and 0.1 W allows for tube overdrive sounds with room volume level
- 1 channel
- 5 watt output power
- 12AX7 preamp tube
- EL84 power tube
- Controls for bass, treble and volume
- Speaker outputs for 8 and 16 Ω
- Robust metal housing


## 4 Installation and starting up

Unpack and carefully check that there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.

Create all connections while the device is off. Use the shortest possible high-quality cables for all connections. Take care when running the cables to prevent tripping hazards.



## 5 Connections and controls



1	[INPUT]
	1/4" phone socket to connect your instrument.
2	[BASS]
	Control for boosting / attenuating the low frequencies.
3	[TREBLE]
	Control for boosting / attenuating the high frequencies.
4	[VOLUME]
	Volume control.
5	[POWER]
	Mains switch. Turns the device on and off.
6	IEC chassis plug for connecting the mains cable with fuse holder. If the fuse blows, replace it with a new fuse of the same type. Blown fuses must never be bridged! If the device still does not work after replacing the fuse, contact a specialist workshop for troubleshooting.



7	[POWER ATTENUATOR]
	Switch to reduce the output power to 1 W or 0.1 W at the 8 $\Omega$ -output. If the switch is in the 5 W position, no power reduction takes place.
8	$[8\Omega]$
	Output for connecting speaker boxes with 8 $\Omega$ impedance.
9	[POWER ATTENUATOR]
	Switch to reduce the output power to 1 W or 0.1 W at the 16 $\Omega$ -output. If the switch is in the 5 W position, no power reduction takes place.
10	[ $16\Omega$ ]
	Output for connecting speaker boxes with 16 $\Omega$ impedance.



# 6 Technical specifications

Output power	max. 5 W @ 8 or 16 $\Omega$
Operating supply voltage	AC 230 V ~ 50/60 Hz
Fuse	5 mm × 20 mm, 1 A, 250 V, slow-blow
Dimensions (W $\times$ H $\times$ D)	205 mm × 127 mm × 140 mm
Weight	3.2 kg



## 7 Plug and connection assignment

#### Introduction

This chapter will help you select the right cables and plugs to connect your valuable equipment in such a way that a perfect sound experience is ensured.

Please note these advices, because especially in 'Sound & Light' caution is indicated: Even if a plug fits into the socket, an incorrect connection may result in a destroyed power amp, a short circuit or 'just' in poor transmission quality!

# 1/4" TS phone plug (mono, unbalanced)



1	Signal
2	Ground, shielding

## 8 Cleaning

### **Device components**

Clean the device components that are accessible from the outside regularly. The cleaning frequency depends on the operating environment: damp, smoky or particularly dirty environments can cause greater accumulation of dirt on the device components.

- Clean with a dry soft cloth.
- Stubborn dirt can be removed with a slightly dampened cloth.
- Never use solvents or alcohol for cleaning.

## 9 Protecting the environment

# Disposal of the packaging material



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

### Disposal of your old device



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.







