Features EN

Controls: HIGH FILTER, BLEND, BASS FILTER

Connectors: 1/4" phone sockets for input and outputs,

power adapter (not included)

Power requirements: Alkaline 9 V battery or external power

supply (DC 9 V ————), both optionally available

Current Draw: 20 mA


Dimensions: $120 \text{ (W)} \times 56 \text{ (H)} \times 95 \text{ (D)} \text{ mm}$


Weight: 380 g

Introduction

The Harley Benton 'Octave' pedal produces a sub-octave note one octave below the note you play. With two filter controls and a SUB switch, the pedal allows you to shape the tone of the sub-octave from deep bass to fuzzy sub-octaves.

You can power this device by an external DC 9 V power adaptor or a 9 V alkaline battery. If you don't use this pedal for a longer period of time take out the battery to avoid leakage. Disconnect the input cable from the pedal when you don't use the device. This disconnects the battery from the circuitry and thus saves its capacity.





This device is intended to be used for effects generating for instrument signals. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

Ensure that plastic bags, packaging, etc. are properly disposed of and are not in the reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts (e.g. knobs or the like) from the product. They could swallow the pieces and choke! Never let children use electrical devices unattended.

For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

Batteries must not be disposed of as domestic waste or thrown into fire. Dispose of batteries according to national or local regulations regarding hazardous waste. To protect the environment, dispose of empty batteries at your retail store or at appropriate collection sites.

Thomann GmbH Hans-Thomann-Str. 1 • 96138 Burgebrach Germany • www.thomann.de

