

# Hero Spot 230



moving head

Musikhaus Thomann Thomann GmbH Hans-Thomann-Straße 1 96138 Burgebrach Germany Telephone: +49 (0) 9546 9223-0 E-mail: info@thomann.de Internet: www.thomann.de

13.11.2020, ID: 477539

## Table of contents

1	Ger	eral information	4			
	1.1	Further information	4			
	1.2	Notational conventions	. 4			
	1.3	Symbols and signal words	5			
2	Safe	ety instructions	7			
3	Fea	tures	11			
4	Inst	allation	12			
5	Sta	rting up	14			
6	Con	nections and controls	15			
7	Оре	erating	17			
	7.1	Starting the device	17			
	7.2	Main menu	17			
	7.3	Operating modes	18			
	7.4	Settings	21			
	7.5	System information	25			
	7.6	Gobos	26			
	7.7	Menu overview	27			
	7.8	Functions in 6-channel DMX mode	27			
	7.9	Functions in 18-channel DMX mode	28			
8	Тес	hnical specifications	33			
9	Plu	g and connection assignment	35			
10	Troubleshooting					
11	Cleaning 3					
12	Protecting the environment					

### 1 General information

This user manual contains important information on the safe operation of the device. Read and follow all safety notes and all instructions. Save this manual for future reference. Make sure that it is available to all persons using this device. If you sell the device to another user, be sure that they also receive this manual.

Our products and user manuals are subject to a process of continuous development. We therefore reserve the right to make changes without notice. Please refer to the latest version of the user manual which is ready for download under <u>www.thomann.de</u>.

### 1.1 Further information

On our website (<u>www.thomann.de</u>) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.		
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.		
Online guides	Our online guides provide detailed information on technical basics and terms.		
Personal consultation	For personal consultation please contact our technical hotline.		
Service	If you have any problems with the device the customer service will gladly assist you.		

### **1.2 Notational conventions**

This manual uses the following notational conventions:

LetteringsThe letterings for connectors and controls are marked by square brackets and italics.Examples: [VOLUME] control, [Mono] button.

Texts and values displayed on the device are marked by quotation marks and italics. **Examples:** '24ch', 'OFF'.

Displays

#### Instructions

The individual steps of an instruction are numbered consecutively. The result of a step is indented and highlighted by an arrow.

#### Example:

- **1.** Switch on the device.
- 2. Press [Auto].
  - $\Rightarrow$  Automatic operation is started.
- **3.** Switch off the device.

#### **Cross-references**

References to other locations in this manual are identified by an arrow and the specified page number. In the electronic version of the manual, you can click the crossreference to jump to the specified location.

Example: See 🖏 'Cross-references' on page 5.

#### **1.3 Symbols and signal words**

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning		
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.		
WARNING!	This combination of symbol and signal word indicates a possible dangerous situation that can result in death or serious injury if it is not avoided.		
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.		
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in mate- rial and environmental damage if it is not avoided.		
Warning signs	Type of danger		
	Warning – high-voltage.		
	Warning – dangerous optical radiation.		
	Warning – suspended load.		

Warning signs	Type of danger
	Warning – danger zone.

## 2 Safety instructions

#### Intended use

This device is intended for use as a freely moving multifunctional spotlight. The device is designed for professional use and is not suitable for use in households. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Extend the operating life of the device by regular breaks and by avoiding frequent switching on and off. The device is not suitable for continuous operation.

#### Safety



### DANGER!

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.



#### **DANGER!**

Electric shock caused by high voltages inside

Within the device there are areas where high voltages may be present. Never remove any covers.

There are no user-serviceable parts inside.

Do not use the device if covers, protectors or optical components are missing or damaged.



### DANGER!

#### Electric shock caused by short-circuit

Always use proper ready-made insulated mains cabling (power cord) with a protective contact plug. Do not modify the mains cable or the plug. Failure to do so could result in electric shock/death or fire. If in doubt, seek advice from a registered electrician.



#### WARNING!

**Eye damage caused by high light intensity** Never look directly into the light source.



## WARNING!

**Risk of epileptic shock** 

Strobe lighting can trigger seizures in photosensitive epilepsy. Sensitive persons should avoid looking at strobe lights.



#### WARNING!

#### Risk of injury caused by falling objects

Make sure that the installation complies with the standards and rules that apply in your country. Always secure the device with a secondary safety attachment, such as a safety cable or a safety chain.

The load capacity of trusses or other fixtures must be sufficient for the intended number of devices. Not that the movement of the head places additional loads on the load-bearing parts.



#### CAUTION!

#### Risk of injury due to movements of the device

The head of the device can move quickly (pan, tilt) and can produce very bright light. This is also valid immediately after you turn on the device, when the device operates in automatic mode or under remote control and when you turn off a DMX controller that is connected to the device. Persons staying near the device could be injured or frightened.

Before you turn on the device and during the operation, always ensure that nobody stays close to the device. If work has to be performed in the area of movement or in the near vicinity of the device, it must remain turned off.

### NOTICE!

**Risk of fire** 

Do not block areas of ventilation. Do not install the device near any direct heat source. Keep the device away from naked flames.

#### NOTICE!

#### Operating conditions

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.

Only operate the device within the ambient conditions specified in the chapter 'Technical specifications' of this user manual. Avoid heavy temperature fluctuations and do not switch the device on immediately after it was exposed to temperature fluctuations (for example after transport at low outside temperatures).

Dust and dirt inside can damage the unit. When operated in harmful ambient conditions (dust, smoke, nicotine, fog, etc.), the unit should be maintained by qualified service personnel at regular intervals to prevent overheating and other malfunction.

The device must not be moved during use.

#### NOTICE!

#### **Power supply**

Before connecting the device, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly injure the user.

Unplug the device before electrical storms occur and when it is unused for long periods of time to reduce the risk of electric shock or fire.

#### NOTICE!

#### Risk of fire by exceeding the maximum current

The device can power further devices via a lockable Power Twist output socket. The current consumption of all further devices connected in series must not exceed the value stated in the technical specifications, otherwise injuries and irreparable damage to the device can occur.

Only connect as many devices to the output socket that the maximum current consumption is not exceeded.

Pay attention to the correct dimensioning (core cross-section) of the power cables used for all devices connected in series.

#### NOTICE!

#### **Possible staining**

The plasticiser contained in the rubber feet of this product may possibly react with the coating of your parquet, linoleum, laminate or PVC floor and after some time cause permanent dark stains.

In case of doubt, do not put the rubber feet directly on the floor, but use felt-pad floor protectors or a carpet.

#### NOTICE!

#### **Risk of overheating**

The distance between light output and the illuminated surface must be more than 1.5 m (19.7in).

Provide sufficient ventilation.

The ambient temperature must always be below 40 °C (104 °F).

### NOTICE!

#### Risk of fire and overheating

The distance between light source and the illuminated surface must be more than 6 m (19.7 ft).

Provide sufficient ventilation.

The ambient temperature must always be below 40 °C.

#### NOTICE!

#### Possible damage due to installation of a wrong fuse

The use of different types of fuses can cause serious damage to the unit. Fire hazard!

Only fuses of the same type may be used.

### 3 Features

Special features of the device:

- 1 × 230 W LED
- Beam angle 11°...25°
- Motorised zoom and focus
- Two moving axes
  - Tilt (260°)
  - Pan (540°)
- Control via DMX (6 or 18 channels) or buttons and display on the unit
- Built-in automatic show programmes
- Sound control
- Master / Slave mode
- Strobe effect
- Electronic dimmer
- Selectable dimmer curves
- Circular and linear prism
- Gobo wheel with 7 rotatable gobos
- Gobo wheel with 7 static gobos
- Colour wheel with 7 colours
- Robust metal and plastic housing

For technological reasons, the light output of LEDs decreases over their lifetime. This effect increases with higher operating temperature. You can extend the service life of the illuminants by providing adequate ventilation and operating the LEDs with the lowest possible brightness.

### 4 Installation

Unpack and check carefully there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the product against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.

Lift the device only at the base. When lifted at the rotatable mounting, the device may be damaged.

You can install the device standing or hanging. When in use, the device must be mounted at a solid surface or clamped to an approved truss.

Work from a stable platform whenever you install or move the device or when you perform any kind of maintenance. Block access under the work area.



#### WARNING!

Risk of injury caused by falling objects

Make sure that the installation complies with the standards and rules that apply in your country. Always secure the device with a secondary safety attachment, such as a safety cable or a safety chain.

The load capacity of trusses or other fixtures must be sufficient for the intended number of devices. Not that the movement of the head places additional loads on the load-bearing parts.

### NOTICE!

#### **Risk of overheating**

The distance between light output and the illuminated surface must be more than 1.5 m (19.7in).

Provide sufficient ventilation.

The ambient temperature must always be below 40 °C (104 °F).


#### NOTICE!

#### Possible data transmission errors

For error-free operation make use of dedicated DMX cables and do not use ordinary microphone cables.

Never connect the DMX input or output to audio devices such as mixers or amplifiers.

#### **Mounting options**



The Quick Lock mounts on the bottom side of the housing (A) allow the secure attachment of the included mounting brackets. There, you can fasten adapters such as half couplers, trigger clamps, c-hooks etc. Safety cables are being threaded through the safety eyelets (B) on the bottom side of the housing.




### 5 Starting up

Create all connections while the device is off. Use the shortest possible high-quality cables for all connections. Take care when running the cables to prevent tripping hazards.

#### **Connections in DMX mode**

Connect the DMX input of the device to the DMX output of a DMX controller or another DMX device. Connect the output of the first DMX device to the input of the second one, and so on to form a daisy chain. Always ensure that the output of the last DMX device in the daisy chain is terminated with a resistor (110  $\Omega$ , ¼ W).




DMX indicator

When the device and the DMX controller are in operation and a DMX signal is received at the input, the status LED [DMX] lights up.

Connections in master/slave mode

When you configure a group of devices in master/slave mode, the first unit will control the other units for an automatic, sound-activated, synchronized show. This function is ideal when you want to start a show immediately. Connect the DMX output of the master device to the DMX input of the first slave device. Then connect the DMX output of the first slave device to the DMX input of the second slave device and so on.

## 6 Connections and controls



1	[DMX]
	Status LED. The LED lights up as soon as a DMX signal is present.
2	[RUN]
	Status LED. This LED lights up once the device is operational.
3	Display
4	[UP]
	Increases the displayed value by one.
5	[SET]
	Activates the main and settings menu. Selects an option of the respective operating mode, confirms the set value.
6	[DOWN]
	Decreases the displayed value by one.
7	[ESC]
	Closes an open submenu without saving any changes.
8	[DMX In]
	DMX input, designed as XLR panel plug, 3-pin
9	[DMX Out]
	DMX output, designed as XLR panel socket, 3-pin
10	[DMX In]
	DMX input, designed as XLR panel plug, 5-pin

### Connections and controls

11	[DMX Out] DMX output, designed as XLR panel socket, 5-pin
12	Fuse holder
13	[Power In] Lockable input socket (Power Twist) for mains power supply
14	[Power Out] Lockable output socket (Power Twist) for powering a connected device Output current 12 A max.

### 7.1 Starting the device



#### Risk of injury due to movements of the device

The head of the device can move quickly (pan, tilt) and can produce very bright light. This is also valid immediately after you turn on the device, when the device operates in automatic mode or under remote control and when you turn off a DMX controller that is connected to the device. Persons staying near the device could be injured or frightened.

Before you turn on the device and during the operation, always ensure that nobody stays close to the device. If work has to be performed in the area of movement or in the near vicinity of the device, it must remain turned off.

Connect the device to the power supply to start operation. After a few seconds, the fans start to work, the head moves to the home positions for rotation (pan) and inclination (tilt). The device is now operational.

### 7.2 Main menu

Press [SET] to activate the main menu.

Use [UP] and [DOWN] to change the respectively displayed value. When the display shows the desired value, press [SET].

To exit the menu item without making changes, press [ESC].

If you don't press any button for 30 seconds the display turns off. A short press on [ESC], [SET], [UP] or [DOWN] will then turn it back on.

All previous settings are retained even when you switch the device off and disconnect it from the mains.

DMX address

Use the 'DMX Address' menu to set the DMX address.

- **1.** Press [SET] to activate the main menu.
- **2.** Use [UP] or [DOWN] until the display shows 'DMX Address' and confirm with [SET].
- **3.** Use [UP] or [DOWN] to select a value between '001' and '512' to set the desired DMX address and confirm with [SET].

Make sure that this number matches the configuration of your DMX controller. The following table shows the respective highest possible DMX address for the various DMX modes.

Mode	Highest possible DMX address
6-channel mode	507
18-channel mode	495

## 7.3 Operating modes

	Set the DMX mode in the <i>'Running Mode'</i> menu.			
DMX mode				
	1.	Press [SET] to activa	te the main menu.	
		Use [UP] or [DOWN] [SET].	until the display sho	ows 'Running Mode' and confirm with
				two DMX modes (6-channel mode or 6CH Mode' or 'DMX 18CH Mode') and
		⇒ The device is no	ow controlled by a D	MX controller.
Auto programmes	In this operating mode you select one of the automatic programmes and adjust the speed as well as the overall brightness of the automatic programme.			
	<b>1.</b> Press [SET] to activate the main menu.			
	<b>2.</b> Press [UP] or [DOWN] until the display shows 'Running Mode' and confirm with [SET].			
	3.	Press [UP] or [DOWN	/] until the display sl	nows 'Auto' and confirm with [SET].
		Press [UP] or [DOWN confirm with [SET].	<i>l]</i> to select the desire	ed submenu or the desired value and
		The following sub m	nenus are available:	
		Menu level 3	Menu level 4	Description
		'Program'	'Program 1 Program 8'	Automatic programme 18
		'Speed'	'0' … '100'	Running speed from slow to fast
		'Master Brightness'	'0' '100 %'	Overall brightness

 $\Rightarrow$  The device plays the selected show in an endless loop.

#### Sound control

In this mode, the unit follows the rhythm of the background music or sounds detected by the built-in microphone.

- **1.** Press [SET] to activate the main menu.
- **2.** Press [UP] or [DOWN] until the display shows 'Running Mode' and confirm with [SET].
- **3.** Press [UP] or [DOWN] until the display shows 'Sound' and confirm with [SET].
- **4.** Press [UP] or [DOWN] to select the desired submenu or the desired value and confirm with [SET].

The following sub menus are available:

Menu level 3	Menu level 4	Description
'Program'	'Program 1 Program 8'	Sound controlled programme 18
'Sensitivity'	'0' '100'	Microphone sensitivity from low to high
'Master Brightness'	'0' … '100 %'	Overall brightness

 $\Rightarrow$  The device plays the selected show in an endless loop.

Master / slave mode

To use a device as the master device, select one of the automatic programmes, activate the sound control or the manual control. Connect the slave devices to the DMX output of the master device and select the DMX mode.

#### Manual operating on the unit

In the 'Running Mode' menu, you can make manual settings for the device parameters.

- **1.** Press [SET] to activate the main menu.
- 2. Use [UP] or [DOWN] until the display shows 'Running Mode' and confirm with [SET].
- 3. Use [UP] or [DOWN] to select the menu item 'Manual Control' and confirm with [SET].
- **4.** Use [UP] or [DOWN] to select the desired parameter and confirm with [SET]. The following sub menus are available:

Menu level 3	Menu level 4/5	Description
'Pan'	'0' '540'	Setting the angle of rotation
'Tilt'	'0' '260'	Setting the angle of inclination
'Pan/Tilt Speed'	'0' '255'	Setting the speed of pan and tilt, increasing speed
'Dimmer'	'0' '255'	Setting the dimmer intensity
'Strobe'	'0' … '30'	Setting the frequency of the strobo- scope, increasing speed
'Color'	Colour setting	Setting one of the seven colours of the colour wheel or white (value ranges such as 18-channel DMX mode, see & Chapter 7.9 'Functions in 18-channel DMX mode' on page 28)
	'color flow forward' '0' '255'	Speed for colour change clockwise, increasing speed
	ʻcolor flow backward' ʻ0ʻ ʻ255'	Speed for colour change counter- clockwise, increasing speed
'Fixed Gobo'	Static Gobo wheel	Setting one of the seven static Gobos
	'gobo flow forward' '0' '255'	Speed for gobo pass clockwise, increasing speed
	ʻgobo flow backward' ʻ0ʻ ʻ255ʻ	Speed for gobo pass counterclock- wise, increasing speed
'Rotatable Gobo'	Rotatable gobo wheel	Setting one of the seven rotatable gobos
	'gobo flow forward' '0' '255'	Speed for gobo pass clockwise, increasing speed



Menu level 3	Menu level 4/5	Description	
	ʻgobo flow backward′ ʻ0ʻ ʻ255'	Speed for gobo pass counterclock- wise, increasing speed	
'Gobo Rotation'	'0' … '255'	Setting the gobo rotation speed, increasing speed	
'Focus'	'0' '255'	Setting the initial focus setting	
'Prism'	'off'	Deactivating the prism	
	'Circular'	Adjusting the circular prism	
	'Linear'	Adjusting the linear prism	
'Prism Rotation'	'stop'	Deactivating rotation	
	'Forward' '0' '255'	Setting the rotation speed of the prism clockwise, increasing speed	
	'Backward' '0' '255'	Setting the rotation speed of the prism counterclockwise, increasing speed	
'Zoom'	'0' … '255'	Setting zoom	

### 7.4 Settings

Use the 'Setting' menu to adjust the basic device parameters.

- **1.** Press [SET] to activate the main menu.
- **2.** Use [UP] or [DOWN] until the display shows 'Setting' and confirm with [SET].

### **3.** Use [UP] or [DOWN] to select the desired parameter.

The following sub menus are available:

Menu level 2	Menu level 3/4	Description			
'Pan Reverse'	Pan inversion	Pan inversion			
	'YES'	reversed direction of rotation			
	'NO'	normal direction of rotation			
'Tilt Reverse'	Tilt inversion				
	'YES'	reversed direction of inclination			
	'NO'	normal direction of inclination			
'Pan Limit'	'Starting point' '0' '539'	Starting point of the rotation angle			
	'Ending point' '1' '540'	Ending point of the rotation angle			
'Tilt Limit'	'Starting point' '0' '259'	Starting point of the inclination angle			
	'Ending point' '1' … '260'	Ending point of the inclination angle			
'Home Position'	Setting the start parameters				
	Detailed information about this menu item can be found under § <i>'Setting the start parameters' on page 24</i> .				
'DMX Fail'	Behaviour on DMX control failure				
	'Hold'	last DMX signal is being held			
	'Blackout'	Blackout on DMX failure			
	'Auto Mode'	Automatic programmes mode on DMX failure			
	'Manual Control'	Manual mode on DMX failure			
	'Sound Mode'	Sound control on DMX failure			
'Dimmer Curve'	Dimmer curves				
	'Linear'	linear proportional course			
	'Exponential'	square curve with a flat course at the beginning and steep course at the end			
	'Logarithmic'	Inverted square curve with a steep course at the beginning and a flat course at the end			
	'S Curve'	Non-linear curve with a distinctive flat course at the beginning and end			



Menu level 2	Menu level 3/4	Description	
'Fan Mode'	Fan setting		
	'Max'	maximum speed	
	'Automatic'	temperature-dependent speed	
	'Silent'	quiet mode with possible reduction of light output	
'Blackout'	Blackout of the device		
	'No'	Blackout off	
	ʻlf XY run'	Blackout if Pan or Tilt active	
	ʻlf colour wheel run'	Blackout if colour wheel active	
	ʻlf gobo wheel run'	Blackout if Gobo wheel active	
'PWM'	Pulse-width modu	lation	
	Options: '650Hz', '1530Hz', '3600Hz', '12KHz' or '25KHz'.		
'Auto Correction'	Auto-correction Pan and Tilt		
	'ON'	Auto-correction activated. The device returns to its starting position if the moving head is unintentionally adjusted	
	'OFF'	Auto-correction disabled (not recom- mended)	
'Display	Display illumination		
Backlight'	'ON'	Illumination permanently on	
	'OFF'	Illumination is switched off after 60 seconds	
'Display Reverse'	Display reversal		
	'ON'	Text in the display appears upside down	
	'OFF'	Text in the display appears normal	
'Autolock'	Key lock		
	'ON'	automatic lock switched on	
		If the key lock is activated, all keys have no function after 60 seconds. To cancel the key lock, press [SET] for 5 seconds.	
	'OFF'	automatic lock switched off	
	Function test		

Menu level 2	Menu level 3/4 Description		
	'Start'	Press [SET] to start the function test. Caution! The device is moving.	
		Press [ESC] to stop the test.	
'Reset Motor'	Resetting the motor		
	'YES'	Motor reset	
	'NO'	no motor reset	
'Factory Reset'	Reset to factory defaults		
	'YES'	Reset to factory defaults	
	'NO'	no reset to factory defaults	

#### Setting the start parameters

Use the 'Home Position' menu to adjust the start parameters of the device.

- **1.** Press [SET] to activate the main menu.
- 2. Use [UP] or [DOWN] until the display shows 'Settings' and confirm the setting with [SET].
- 3. Use [UP] or [DOWN] to select the submenu 'Home Position' and confirm with [SET].
  - $\Rightarrow$  The device prompts you to enter a password.

Press [UP] or [DOWN] repeatedly until the display shows '018' and confirm the selection with [SET].



**4.** Use [UP] or [DOWN] to select the parameter you want to set and confirm with [SET].

Menu level 3	Menu level 4	Description
'Pan'	'–128' '127'	Setting the home position of the rotary movement
'Tilt'	'–128' '127'	Setting the home position of the inclina- tion movement
'Dimmer'	'0' '255'	Setting the initial dimmer intensity
'Color '	'–128' … '127'	Specifying the initial colour wheel setting
'Fixed Gobo'	'–128' '127'	Specifying the initial setting for the static gobo wheel
'Rotatable Gobo'	'–128' '127'	Specifying the initial setting for the rotat- able gobo wheel
'Focus'	'–128' … '127'	Specifying the initial focus setting
'Zoom'	'–128' … '127'	Specifying the initial zoom setting
'Prism'	'–128' … '127'	Specifying the initial prism setting
'Gobo Rotation'	'–128' … '127'	Specifying the initial rotation setting

The following sub menus are available:

## 7.5 System information


Use the 'System Info' menu to call up information about the system.

- **1.** Press [SET] to activate the main menu.
- **2.** Use [UP] or [DOWN] until the display shows 'System Info' and confirm the setting with [SET].
- **3.** Use [UP] or [DOWN] to select the information you want to display and confirm with [SET].


Parameter	Function
'Current Time'	Displays the current running time of the device.
'Total Time'	Displays the total running time of the device.
'LED on Time'	Displays the total running time of the LED.
'Current Mode '	Displays the current operating mode.
'Temperature Head'	Displays the current head temperature.
'Temperature Base'	Displays the current temperature of the device base.
'Software Version'	Displays the current software version.

### 7.6 Gobos

### Static Gobo wheel




### Rotatable gobo wheel





### 7.7 Menu overview



### 7.8 Functions in 6-channel DMX mode

Channel	Value	Function	
1	0255	Rotation (pan) (0° up to the maximum value of the Pan range)	
2	0255	Inclination (tilt) (0° up to the maximum value of the Tilt area)	
3	0255	Dimmer intensity from dark (0) to bright (255)	
4	Stroboscope		
	010	LEDs off	

Channel	Value	Function	
	1180	Constantly increasing brightness, increasing speed (dimmed bright, quickly dark)	
	81140	Constantly decreasing brightness, increasing speed (quickly bright, dimmed dark)	
	141200	Impulse effect, increasing speed (dimmed light and dark)	
	201250	Strobe effect, constant (0.520 Hz)	
	251255	LEDs on	
5	07	No function	
	847	Preprogrammed automatic show 1	
	4887	Preprogrammed automatic show 2	
	88127	Preprogrammed automatic show 3	
	128167	Preprogrammed automatic show 4	
	168207	Preprogrammed automatic show 5	
	208247	Preprogrammed automatic show 6	
	248255	Sound control colour wheel	
6	07	No function	
	832	Pan-Tilt auto programme 1	
	3358	Pan-Tilt auto programme 2	
	5984	Pan-Tilt auto programme 3	
	85110	Pan-Tilt auto programme 4	
	111136	Pan-Tilt auto programme 5	
	137162	Pan-Tilt auto programme 6	
	163188	Pan-Tilt auto programme 7	
	189214	Pan-Tilt auto programme 8	
	215255	Sound control Pan and Tilt	

### 7.9 Functions in 18-channel DMX mode

Channel	Value	Function
1	0255	Rotation (pan) (0° up to the maximum value of the Pan range)
2	0255	Fine adjustment rotation (pan)
3	0255	Inclination (tilt) (0° up to the maximum value of the Tilt area)
4	0255	Fine adjustment inclination (tilt)
5	0255	Speed of rotation (pan) and inclination (tilt), fast (0) to slow (255)

Channel	Value	Function		
6	0255	Dimmer intensity from dark (0) to bright (255)		
7	Stroboscope			
	010	LEDs off		
	1180	Constantly increasing brightness, increasing speed (dimmed bright, quickly dark)		
	81140	Constantly decreasing brightness, increasing speed (quickly bright, dimmed dark)		
	141200	Impulse effect, increasing speed (dimmed light and dark)		
	201250	Strobe effect, constant (0.520 Hz)		
	251255	LEDs on		
8	Colour wheel			
	04	Open (white)		
	513	White / 3000 K filter		
	1422	3000 K filter		
	2331	3000 K filter / red		
	3240	Red		
	4149	Red / dark blue		
	5058	Dark blue		
	5967	Dark blue / green		
	6876	Green		
	7785	Green / magenta		
	8694	Magenta		
	95103	Magenta / yellow		
	104112	Yellow		
	113121	Yellow / light blue		
	122130	Bright blue		
	131139	Open (white)		
	140195	Rainbow effect, rotation clockwise, decreasing speed		
	196199	Stop rotation		
	200255	Rainbow effect, rotation counter-clockwise, increasing speed		
9	static Gobo wheel			
	07	Open (white)		
	817	Gobo 1		
	1827	Gobo 2		

Channel	Value	Function
	2837	Gobo 3
	3847	Gobo 4
	4857	Gobo 5
	5867	Gobo 6
	6877	Gobo 7
	7887	Gobo 1 shake, increasing speed
	8897	Gobo 2 shake, increasing speed
	98107	Gobo 3 shake, increasing speed
	108117	Gobo 4 shake, increasing speed
	118127	Gobo 5 shake, increasing speed
	128137	Gobo 6 shake, increasing speed
	138147	Gobo 7 shake, increasing speed
	148199	Gobo pass, rotation clockwise, decreasing speed
	200203	Stop rotation
	204255	Gobo pass, rotation counter-clockwise, increasing speed
10	Rotatable gobo w	heel
	07	Open (white)
	817	Gobo 1
	1827	Gobo 2
	2837	Gobo 3
	3847	Gobo 4
	4857	Gobo 5
	5867	Gobo 6
	6877	Gobo 7
	7887	Gobo 1 shake, increasing speed
	8897	Gobo 2 shake, increasing speed
	98107	Gobo 3 shake, increasing speed
	108117	Gobo 4 shake, increasing speed
	118127	Gobo 5 shake, increasing speed
	128137	Gobo 6 shake, increasing speed
	138147	Gobo 7 shake, increasing speed
	148199	Gobo pass, rotation clockwise, decreasing speed


Channel	Value	Function	
	200203	Stop rotation	
	204255	Gobo pass, rotation counter-clockwise, increasing speed	
11	Rotatable gobo wheel		
	07	Stop rotation	
	847	Gobo index (static position)	
	48127	Gobo wheel 2, rotation clockwise, decreasing speed	
	128137	Stop rotation	
	138255	Gobo wheel 2, rotation counter-clockwise, increasing speed	
12	0255	Focus	
13	0255	Zoom	
14	Prism		
	07	Open (white)	
	899	Circular prism	
	100130	Open (white)	
	131255	Linear prism	
15	Prism rotation		
	07	Stop rotation	
	8129	Prism, rotation clockwise, decreasing speed	
	130133	Stop rotation	
	134255	Prism, rotation counterclockwise, increasing speed	
16	07	No function	
	847	Preprogrammed automatic show 1	
	4887	Preprogrammed automatic show 2	
	88127	Preprogrammed automatic show 3	
	128167	Preprogrammed automatic show 4	
	168207	Preprogrammed automatic show 5	
	208247	Preprogrammed automatic show 6	
	248255	Sound-controlled show	
17	07	No function	
	832	Pan-Tilt auto programme 1	
	3358	Pan-Tilt auto programme 2	
	5984	Pan-Tilt auto programme 3	

Channel	Value	Function
	85110	Pan-Tilt auto programme 4
	111136	Pan-Tilt auto programme 5
	137162	Pan-Tilt auto programme 6
	163188	Pan-Tilt auto programme 7
	189214	Pan-Tilt auto programme 8
	215255	Sound control Pan and Tilt
18	8 0189 No function	
	190210	Reset, if the value is transmitted for at least 10 seconds
	211255	No function



## 8 Technical specifications





1 × 230 W LED	
Beam angle	11°25°, adjustable via motorised zoom
	540°
	260°
DMX, buttons and display of	on the unit
6, 18	
Voltage supply	lockable input socket (Power Twist)
DMX control	2 × XLR chassis plug, 3 and 5-pin
Power supply for further devices	lockable output socket (Power Twist)
	Output current 12 A max.
DMX control	2 × XLR chassis socket, 3 and 5-pin
250 W, max	
100 - 240 V ~ 50/60 Hz	
5 mm × 20 mm, 4 A, 250 V, fast-acting	
IP20	
hanging, standing	
303 mm × 457 mm × 188 mm	
12.7 kg	
Temperature range	0 °C40 °C
	Beam angle DMX, buttons and display of 6, 18 Voltage supply DMX control DMX control DMX control DMX control 250 W, max 100 - 240 V ~ 50/60 Hz 5 mm × 20 mm, 4 A, 250 V, IP20 hanging, standing 303 mm × 457 mm × 188 m 12.7 kg

### **Further information**

Rotating gobos	Yes
Static gobos	Yes
Motorized focus	Yes
Colour mixture	Colour wheel
Prism	Yes
Iris	No
Zoom	Yes
Number of colour wheels	1

## 9 Plug and connection assignment

#### Introduction

**DMX connections** 



**DMX connections** 



This chapter will help you select the right cables and plugs to connect your valuable equipment so that a perfect light experience is guaranteed.

Please take our tips, because especially in 'Sound & Light' caution is indicated: Even if a plug fits into a socket, the result of an incorrect connection may be a destroyed DMX controller, a short circuit or 'just' a not working light show!

The unit offers a 3-pin XLR socket for DMX output and a 3-pin XLR plug for DMX input. Please refer to the drawing and table below for the pin assignment of a suitable XLR plug.

Pin	Configuration
1	Ground, shielding
2	Signal inverted (DMX–, 'cold signal')
3	Signal (DMX+, 'hot signal')

A five-pin XLR socket serves as DMX output, a five-pin XLR plug serves as DMX input. The drawing below and the table show the pin assignment of a matching coupling.

Pin	Assignment
1	Ground (shielding)
2	Signal inverted (DMX–, 'cold')
3	Signal (DMX+, 'hot')
4	unused / second connection (DMX-)
5	unused / second connection (DMX+)

## 10 Troubleshooting

## NOTICE!

Possible data transmission errors

For error-free operation make use of dedicated DMX cables and do not use ordinary microphone cables.

Never connect the DMX input or output to audio devices such as mixers or amplifiers.

In the following we list a few common problems that may occur during operation. We give you some suggestions for easy troubleshooting:

Symptom	Remedy
The unit does not work, no light, the fan does not run	Check the mains connection and main fuse.
No response to the DMX con- troller	1. The status LED [ <i>DMX</i> ] should light up. If it doesn't, check the DMX connectors and cables for proper connection.
	2. If the status LED [DMX] lights up and there is no reaction, check the address settings and the DMX polarity.
	3. Try using another DMX controller.
	4. Check whether the DMX cables run near or par- allel to high-voltage cables that may cause damage or interference to a DMX interface circuit.

If the procedures recommended above do not succeed, please contact our Service Center. You can find the contact information at <u>www.thomann.de</u>.

## 11 Cleaning

**Optical lenses** 

Clean the optical lenses, that are accessible from the outside, regularly in order to optimize the light output. The frequency of cleaning depends on the operating environment: wet, smoky or particularly dirty surroundings can cause more accumulation of dirt on the optics of the device.

- Clean with a soft cloth using our lamp and lens cleaner (item no. 280122).
- Always dry the parts carefully.

**Fan grids** 

The fan grids of the device must be cleaned of any contamination, such as dust, etc. on a regular basis. Before cleaning, switch off the device and disconnect mains-operated devices from the mains. Only use pH-neutral, solvent-free and non-abrasive cleaning agents. Clean the unit with a slightly damp lint-free cloth.

## 12 Protecting the environment

Disposal of the packaging material



Disposal of your old device



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.