MOUNTING INSTRUCTIONS

ABSORBER

These instructions are for the following product: PET Pendant Absorber 30, PET Pendant Absorber 40, PET Pendant Absorber 50

TIP:

Make sure to examine the condition and load carrying capacity of the ceiling before installation.



TOOLS

The following tools are needed for installation:

- √ Drilling machine √ Pencil √ Level
- √ Drill bits √ Folding ruler

MOUNTING ACCESSORIES

The following mounting accessories are included for installation of the absorber:

 \checkmark 4 × dowel √ 4 × adjustable wire rope \checkmark 4 × screw M4×40

 \checkmark 4 × eyelet

√ 2 × PET fleece absorber





UNBOXING

Open the package carefully! Inserting sharp objects into the package can damage the absorber. Avoid using long, sharp tools for opening the package!

REMOVE PRODUCTS FROM PACKAGING

Carefully remove the products from the package and read the mounting instructions carefully. Remove the mounting accessories and the absorber.



Lakustik

DETERMINE THE POSITION

Measure the distances of the dowels inserted in the side of the absorber and mark the measured distances for the drilling holes at the ceiling.



DRILL THE HOLES

Drill the holes at the markings using the drilling machine.

INSERT DOWELS + FASTEN HOLDER

Insert the dowels into the drilled holes and fasten the holder of the wire ropes with two screws M4×40 to the ceiling.

Make sure that the included screws are suitable for the condition of the ceiling.



FIX THE WIRE ROPE

Insert the two screw threads of the wire ropes in the holder and fasten the screw threads. Make sure that the wire ropes are guided through the recess of the holder.

FIX EYELETS

Screw two eyelets into each of the dowels inserted in the side of the absorber.



takustik



FIX THE ABSORBER TO THE WIRE ROPES

Insert the hooks of the adjustable wire ropes into the eyelets of the absorber.

ADJUSTING HEIGHT

Adjust the height of the absorber as you wish.

Fix the excess wire rope using cable straps.





USING ABSORBER

Now you can use the absorber.









This product is intended to be used to optimise the room acoustics. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.



Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.