

Quick Start Guide

This quick start guide contains important information on the safe operation of the product. Read and follow the safety advice and instructions given. Retain the quick start guide for future reference. If you pass the product on to others please include this quick start guide.

Safety instructions

Intended use

This device is used for the sequenced supply of mains voltage via multiple socket outlets. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke! Never let unattended children use electrical devices.

Where to use the product

- Never use the product • in direct sunlight
- in conditions of extreme temperature or humidity
- in extremely dusty or dirty areas
- at locations where the unit can become wet
- near magnetic fields

General handling

To prevent damage, never use force when operating the switches and controls.
Never immerse the appliance in water. Just wipe it with a clean dry cloth. Do not use liquid cleaners such as benzene, thinners or flammable cleaning agents.

Keep foreign substances from the unit!

Keep the device away from containers with liquids. Should any liquid get into the unit, this could lead to its destruction or fire. Be sure not to let any metal objects into the unit.

Features

- AC power sequencer
- Max. 10 A per safety socket, max. 16 A in total
- $8 \times$ sequenced sockets on the back
- 1 × socket on the front
- Voltage monitoring
- Voltage monitoring



- Adjustable sequence times via the front display
- C16 circuit breaker

Supply voltage:

- Dimensions ($W \times H \times D$):
- Weight:

230 V~ 50 Hz 482 mm × 88 mm × 277 mm | 19" / 2 RU 4.8 kg

1. Circuit breaker

- 2. Front socket
- 3. Display
- 4. MENU: Switch / knob for entering values
- 5. POWER: Turns the device on / off
- 6. Power cord
- 7. Rear sockets

Using the device

- 1. Install the device in a 19 "rack, if desired.
- 2. Use the power cord to connect the device to a properly connected power outlet that provides the voltage specified here.
- Press the POWER switch to turn on the unit. The display then shows the date, time and the supply voltage. In the channel display at the bottom of the display, the sockets connected to devices are displayed in green, free sockets in red.
- 4. Turn the MENU knob until the display shows SYSTEM SET. Here you can save and load up to 8 configurations, select the language for the display. Each time you change a value, press the MENU knob to save the change.
- 5. Turn the MENU knob until the display shows PROTECT SET. Press the MENU knob. Now you can select [On], [Off] or [Auto].



7. Press and hold the MENU knob for a few seconds until a lock icon appears in the display. The function for changing values is now protected against unintentional use. Press and hold the MENU knob again for a few seconds until the lock icon disappears. The function for changing values is now available again.

5. Turn the MENU knob until the display shows TIME SET. Press the

MENU knob. Now you can set the date and time, turn auto-start

8. Press the POWER switch to turn off the power.



DELAY SET CH1 ON DELAY: 3 s OFF DELAY: 7 s 2014-09-20 14:00:29 a ~225 V

1234567

For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging. This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

SYSTEM SET AVE:Model 1

ALL:Model 2 ANGUAGE:Chir

PROTECT SET

OVP:270 V

EN