



Desktop Microphone Station

Quick Start Guide

This quick start guide contains important information on the safe operation of the product. Read and follow the safety advice and instructions given. Retain the quick start guide for future reference. If you pass the product on to others please include this quick start guide.

Safety instructions

Intended use

This call station base, together with a suitable microphone, forms a desk call station. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

Danger for children



Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts from the product. They could swallow the pieces and choke! Never let children unattended use electrical devices!

Where to use the product

Never use the product

- outdoors
- in conditions of extreme temperature or humidity
- in extremely dusty or dirty areas
- at locations where the unit can become wet

General handling

- To prevent damage, never use force when handling the product.
- Never immerse the product in water. Just wipe it with a clean dry cloth. Do not use liquid cleaners such as benzene, thinners or flammable cleaning agents.


Leistungsmerkmale

- Microphone desk station with anti-shock microphone connection
- Click-free switching
- Switchable between "PUSH TO TALK" and "PUSH TO MUTE"
- Indicator LED


- 3-pin XLR connectors
- Voltage supply via 48 V phantom power
- Non-slip zinc die-cast base

Operating elements


Top side



Bottom side



Rear side



- 1 Release button for the XLR microphone connection
- 2 XLR microphone connector
- 3 Toggle switch for the function of the talk button
- 4 Talk button
- 5 Connection for the XLR connection cable

Using the product

1. Attach a microphone via a suitable holder, e.g. a gooseneck to the XLR microphone connector. Before you want to separate the holder from the call station base - if necessary -, first press the release button for the XLR microphone connection.
2. Connect the XLR connection on the rear side via a suitable XLR cable to the device to which the microphone signals are to be transmitted.
3. Activate phantom power on the device connected to the desk call station.
4. Use the toggle switch on the bottom to select the desired function for the talk button. When the switch is in the "PUSH TO TALK" position, the microphone signals are only transmitted while the talk button is pressed. When the switch is in the "PUSH TO MUTE" position, the microphone signals are transmitted continuously and are only muted while the talk button is pressed.
5. While the talk button is pressed, the LED above the talk button lights up.

Technical specifications

Dimensions (W × H × D): 125 mm × 40 mm × 120 mm
Weight: 1.2 kg

Ambient conditions

Temperature range 0 °C - 40 °C
Relative humidity 20 % - 80 % (non-condensing)



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.