

Quick start guide

This document contains important information on the safe use of the product. Read and follow the safety instructions and all other instructions. Keep the document for future reference. If you pass the product on to others, please include this document. Contents are subject to change. Please refer to the latest version of the documentation, which is available for download at www.thomann.de.

Safety instructions

Intended use

This device is intended to be used for the wireless transmission of audio signals, particularly voice transmission during guided tours and events. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damage resulting from improper use. This device may be used only by persons with sufficient physical, sensory, and intellectual abilities and the necessary knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Risk of injury and choking hazard for children!



Children can suffocate on packaging material and small parts. Children can injure themselves when handling the device. Never allow children to play with the packaging material and the device. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the device without supervision. Keep small parts away from children and make sure that the device does not shed any small parts (such as knobs) that children could play with.

Damage to the external power supply due to high voltages!



The device is powered by an external power supply. The external power supply can be damaged if it is operated with the incorrect voltage or if high voltage peaks occur. In the worst case, excess voltages can also cause a risk of injury and fires. Make sure that the voltage specification on the external power supply matches the local power grid before plugging in the power supply. Only operate the external power supply from professionally installed mains sockets that are protected by a residual current circuit breaker (FI). As a precaution, disconnect the power supply from the power grid when storms are approaching or if the device will not be used for a longer period.

Damage to the device if operated in unsuitable ambient conditions!



The device can be damaged if it is operated in unsuitable ambient conditions. Only operate the device indoors within the ambient conditions specified in the "Technical specifications". Avoid operating it in environments with direct sunlight, heavy dirt and strong vibrations. Avoid operating it in environments with strong temperature fluctuations. If temperature fluctuations cannot be avoided (for example after transport in low outside temperatures), do not switch on the device immediately. Never subject the device to liquids or moisture. Never move the device to another location while it is in operation. In environments with increased dirt levels (for example due to dust, smoke, nicotine or mist): Have the device cleaned by qualified specialists at regular intervals to prevent damage due to overheating and other malfunctions.

General handling

- To prevent damage, never exert force while operating the device.
- Never immerse the device in water. Wipe only with a clean and dry cloth. Do not use liquid cleaners such as benzene, thinners or flammable cleaning agents

Keep the device away from impurities!


Keep the device away containers with liquid. Should liquid enter the device, this could lead to its destruction or fire. Ensure that no metallic parts enter the device.

Features

- 18 charging slots for bodypack transmitter TG 16 T and bodypack receiver TG 16 R
- Separate indicator LED for each charging slot
- Power supply via supplied power supply
- Installed in a handy and robust portable case

Connections and controls

1. 18 charging slots for bodypack transmitters or receivers, with separate indicator LED. The LED flashes when the charging slot is free. It lights up when charging begins and then goes out after about 10 to 15 seconds.
2. [DC Input] | Connection for the supplied power supply
3. [POWER] | Mains switch for turning the device on and off. The integrated LED indicates that the device is on.



Operation

Preparing the device

Connect the supplied power supply to the power supply input of the device and then plug the power adapter into a mains socket. Turn on the device with the main switch. The integrated indicator LED lights up red.

Charging bodypack devices

Turn off the bodypack transmitter or receiver that needs charging. Position the charging contacts of the bodypack device over the charging contacts of the charging slot, then insert the bodypack device into the charging slot so that it engages. The indicator LED of the charging slot turns off. It lights up again when the device is fully charged.

Technical specifications

| | | | | |
|---------------------|-----------------------------|---|------------------------|--|
| Battery | Battery type | Lithium-ion | Dimensions (W × H × D) | 361 mm × 189 mm × 422 mm |
| | Voltage | 3.7 V | Weight | 3.4 kg |
| | Charging time in the device | approx. 8 h | Ambient conditions | Temperature range 0 °C...40 °C |
| Charging slots | | 18 | | Relative humidity 20%...80% (non-condensing) |
| Power supply | External power supply | 100 - 240 V 50/60 Hz | | |
| Operating voltage | | 15 V $\overline{=}$ / 3.3 A , centre positive | | |
| Current consumption | | 400 mA | | |



Discover the entire t.bone range on our website:
tbone.audio



Visit us on Instagram and discover the full audio experience:
[tbone.audio/instagram](https://www.instagram.com/tbone.audio)



Visit our YouTube channel for product videos and interesting stories:
[tbone.audio/youtube](https://www.youtube.com/tbone.audio)



Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner. Do not dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the instructions and markings on the packaging.



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) as amended. Do not dispose of your old device with your normal household waste; instead, deliver it for controlled disposal by an approved waste disposal firm or through your local waste facility. When disposing of the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste management facility.

Proper disposal protects the environment as well as the health of your fellow human beings.

Also note that waste avoidance is a valuable contribution to environmental protection. Repairing a device or passing it on to another user is an ecologically valuable alternative to disposal.

You can return your old device to Thomann GmbH at no charge. Check the current conditions on www.thomann.de. If your old device contains personal data, delete those data before disposing of it.



Observe the disposal note regarding documentation in France.