



furgeneration

PL 108 P / 110 P /
112 P / 115 P

passive 2-way speaker

Musikhaus Thomann
Thomann GmbH
Hans-Thomann-Straße 1
96138 Burgebrach
Germany
Telephone: +49 (0) 9546 9223-0
E-mail: info@thomann.de
Internet: www.thomann.de

05.04.2017, ID: 383468_383471_383472_402991 (V2)

Table of contents

1	General information	4
	1.1 Further information.....	5
	1.2 Notational conventions.....	6
	1.3 Symbols and signal words.....	6
2	Safety instructions	8
3	Features	10
4	Installation	11
	4.1 Tips on handling speakers.....	13
	4.2 Connections.....	14
5	Technical specifications	18
6	Plug and connection assignment	22
7	Cleaning	23
8	Protecting the environment	24

1 General information

This manual contains important instructions for the safe operation of the unit. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the device. If you sell the unit please make sure that the buyer also receives this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change.

1.1 Further information

On our website (www.thomann.de) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.

1.2 Notational conventions

This manual uses the following notational conventions:


Letterings

The letterings for connectors and controls are marked by square brackets and italics.

Examples: *[VOLUME]* control, *[Mono]* button.

1.3 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – danger zone.

2 Safety instructions

Intended use

This device is intended to be used in a sound reinforcement system. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.



DANGER!

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.



CAUTION!

Possible hearing damage

The device can produce volume levels that may cause temporary or permanent hearing impairment. Over an extended period of time, even levels that seem to be uncritical can cause hearing damage.

Decrease the volume level immediately if you experience ringing in your ears or hearing impairment. If this is not possible, keep a greater distance or use sufficient ear protectors.

3 Features

- passive 2-way speaker
- maximum load capacity 320 W, 480 W, 600 W or 800 W (depending on the model)
- 8", 10", 12 or 15" woofer (depending on the model)
- 1" tweeter
- 2 × lockable NL4 chassis connectors (IN/OUT)
- solid plastic housing with pole mount and handles

4 Installation

Unpack and carefully check that there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.



NOTICE!

Possible property damage by magnetic fields

Loudspeakers produce a static magnetic field. Therefore, maintain an appropriate distance to devices that can be adversely affected or damaged by an external magnetic field.



NOTICE!

Use of stands

When mounting the device onto a stand, ensure that the stand is in a safe and stable position and that the weight of the device does not exceed the maximum permissible load capacity of the stand.

4.1 Tips on handling speakers

We recommend you to set up the speakers in a way, that the sound signals can reach the audience unobstructedly. It will often be helpful to mount the speakers on tripods. Thus, the sound will be evenly spread with maximum range throughout the audience area.


Always use high grade cable to connect your equipment. Otherwise you won't reach maximum sound quality.

For optimum results both impedance and power handling of the speakers must match the requirements of the amplifier. Always follow the technical specifications of the speakers! The overall impedance of the connected loudspeakers must not exceed the minimum output impedance of the amp. The amp's max. RMS output power should be 50 % above the power handling capacity of the connected speakers.


If you notice distortion during operation, either the amp or the speaker is overloaded. This may permanently damage the amp or the speaker. Always reduce the volume when you hear distortion.

4.2 Connections

Model PL 108 P




Model PL 110 P




PL 108 P / 110 P / 112 P / 115 P

Model PL 112 P



Model PL 115 P



1 [INPUT]

Lockable NL4 chassis connector for signal input (1+/1-).

2 [OUTPUT]

Lockable NL4 chassis connector output for connecting an additional passive speaker box (1+/1-).

PL 108 P / 110 P / 112 P / 115 P

5 Technical specifications

PL 108 P

System	Passive 2-way speaker
Configuration	1 × 8" woofer, 1 × 1" tweeter
Connections	2 × NL4 (IN/OUT)
Power handling	320 W (peak)
Impedance	8 Ω
Sound pressure level (max.)	107 dB
Frequency range	90 Hz - 18 kHz
Dimensions (W × H × D)	245 mm × 390 mm × 195 mm
Weight	3.8 kg

PL 110 P

System	Passive 2-way speaker
Configuration	1 × 10" woofer, 1 × 1" tweeter
Connections	2 × NL4 (IN/OUT)
Power handling	480 W (peak)
Impedance	8 Ω
Sound pressure level (max.)	109 dB
Frequency range	80 Hz - 18 kHz
Dimensions (W × H × D)	310 mm × 495 mm × 250 mm
Weight	5.6 kg

PL 112 P

System	Passive 2-way speaker
Configuration	1 × 12" woofer, 1 × 1" tweeter
Connections	2 × NL4 (IN/OUT)
Power handling	600 W (peak)
Impedance	8 Ω
Sound pressure level (max.)	114 dB
Frequency range	80 Hz - 19 kHz
Dimensions (W × H × D)	375 mm × 585 mm × 295 mm
Weight	9.8 kg

PL 115 P

System	Passive 2-way speaker
Configuration	1 × 15" woofer, 1 × 1" tweeter
Connections	2 × NL4 (IN/OUT)
Power handling	800 W (peak)
Impedance	8 Ω
Sound pressure level (max.)	116 dB
Frequency range	70 Hz - 19 kHz
Dimensions (W × H × D)	740 mm × 480 mm × 390 mm
Weight	11 kg

6 Plug and connection assignment

Introduction

This chapter will help you select the right cables and plugs to connect your valuable equipment in such a way that a perfect sound experience is ensured.

Please note these advices, because especially in 'Sound & Light' caution is indicated: Even if a plug fits into the socket, an incorrect connection may result in a destroyed power amp, a short circuit or 'just' in poor transmission quality!

NL4 mounting connectors



1, +	Signal 1 (in phase)
1, -	Signal 1 (180 degree phase shift)
2, +	Signal 2 (in phase)
2, -	Signal 2 (180 degree phase shift)

7 Cleaning

Device components

Clean the device components that are accessible from the outside regularly. The cleaning frequency depends on the operating environment: damp, smoky or particularly dirty environments can cause greater accumulation of dirt on the device components.

- Clean with a dry soft cloth.
- Stubborn dirt can be removed with a slightly dampened cloth.
- Never use solvents or alcohol for cleaning.

Fan grids

The fan grids of the device must be cleaned on a regular basis to remove dust and dirt. Before cleaning, switch off the device and disconnect AC-powered devices from the mains. Use a lint-free damp cloth for cleaning. Never use solvents or alcohol for cleaning.

8 Protecting the environment

Disposal of the packaging material



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

Disposal of your old device



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE). Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

PL 108 P / 110 P / 112 P / 115 P



