

User manual

This manual contains important information on the safe operation of the product. Read and follow the safety advice and instructions given. Retain the manual for future reference. If you pass the product on to others please include this manual.

Safety instructions

Intended use

This device is used for hanging and rotating a suitable mirror ball as well as to create decorative lighting effects in indoor areas. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

Danger for children



Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts from the product. They could swallow the pieces and choke!

Where to use the product

Never use the product

- in conditions of extreme temperature or humidity
- in extremely dusty or dirty areas
- at locations where the unit can become wet

General handling

- To prevent damage, never use force when handling the product.
- Never immerse the product in water. Just wipe it with a clean dry cloth. Do not use liquid cleaners such as benzene, thinners or flammable cleaning agents.

Risk of injury caused by falling objects



Make sure that the installation complies with the standards and rules that apply in your country. Always secure a mirror ball attached to the device by a secondary safety attachment, such as a safety cable or a safety chain.

Risk of epileptic shock



Strobe lighting can trigger seizures in photosensitive epilepsy. Sensitive persons should avoid looking at strobe lights.

Perform safety test!



This fixture for hanging a mirror ball must be capable of bearing the 10-fold weight of the mirror ball for one hour without showing any sustaining deleterious deformations.

During building, changing and dismantling the stage, any unnecessary stay in the movement areas, on lighting trusses, below elevated workplaces and other hazardous areas is prohibited.

The contractor must ensure that all safety-related technical equipment and machinery is inspected **by experts before the first commissioning** and any re-commissioning after major changes.

The contractor must ensure that all safety-related technical equipment and machinery is inspected by an expert at least every four years in the scale of the acceptance review.

The contractor must ensure that all safety-related technical equipment and machinery is inspected by a qualified person at least once a year.


The contractor must ensure that all rigging gear is inspected by a qualified person before each using. The inspection must include a visual inspection and load tests in motion.

Article description

- Mirror ball motor with built-in LED illumination
- For mirror balls up to max. 40 cm diameter
- Operation via mains adapter or included rechargeable battery
- Additional rechargeable battery for longer operation optionally available, not included (item number 385488)
- Three 6 W multi-colour LEDs placed around the mirror ball ensure uniform illumination and beautiful play of colours in every kind of room
- Automatic programmes and sound control
- Infrared remote control included
- Dimmable 0 - 100 %
- Stroboscope effect
- Black metal housing with hanging lug on top side

Technical specifications

- Light source: 3 × 6 W RGBW LED
- Beam angle of LEDs: 15°
- Rechargeable battery life in auto mode and at highest rotation speed: approx. 3 hours (per battery)
- Charging time in the unit: approx. 3 hours
- Voltage supply: 15 V / 3 A —
- Dimensions (W × H × L): 370 × 170 × 425 mm
- Weight: 2.18 kg, (w/o battery and mirror ball)



IR remote control

1. Static colour

First select a static colour with R, G, B or W. Then you can further adjust this colour with UP / DOWN.

2. Auto modes

First, press AUTO 1 or AUTO 2. Then, use UP / DOWN to select auto modes AUTO 1 to AUTO 6. To set the desired speed for operation in auto mode, first press SPEED and then use UP / DOWN to set the desired speed. 'UP' stands for a high speed, 'DOWN' for a low one.

3. Sound control

First press SOUND 1 or SOUND 2. You can then select the sound modes SOUND 1 to SOUND 6 with UP / DOWN.

4. Setting the direction of motor rotation

Press 0 to change the direction of rotation. Then press SPEED to change the speed of the rotation with UP / DOWN.



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.