

# PSA 322-6 Digital Line

# **Power Distributor**





# Features

- Power distributor 32A with digital measuring instrument
- Outputs rear panel:
  6 × safety socket (2 per phase)
  6 × Power Twist (2 per phase)
  1 × 32 A / 400 V appliance outlet
- Rear input: CEE 32 A / 400 V plug with cable (H07RN-F 5G6mm<sup>2</sup>)
   Front: 3 × phase light
  - $1 \times digital$  measuring instrument
- For indoor use
- Clear allocation of fuses and outputs using letters

# Safety instructions

#### Intended use This device is used to distribute mains voltage to several consumers. Any other use or use under other operating conditions is considered to

Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

#### Dangers for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke! Never let children unattended use electrical devices.

### Operating conditions

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.

# Electric shock caused by high voltages inside

Within the device there are areas where high voltages may be present. Never remove any covers. There are no user-serviceable parts inside.

- LED display for voltage present per phase
- 19" housing for rack mounting
- Fuses: 6 × RCBO C16
- Residual current switch-off: 30 mA

	Residual current type:	A
1	Supply voltage:	400 V ~ 50 Hz, 32 A per phase
	Housing material:	Metal
	Protection type:	IP 20
	Installation height:	3 RU
	Dimensions (W $\times$ H $\times$ D):	$482 \times 133 \times 227 \text{ mm}$
	Weight:	2.85 kg

# Handling the supply cord

Do not place the device or speaker boxes or similar on the supply cord and be careful not to pinch it. Never tie a knot in the supply cord or tie it with other cables. Route the supply cord so that no one steps on or trips over it. A damaged supply cord can cause a fire or electric shock. Replace any broken cables.

# Protecting the environment

For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

Thomann GmbH Hans-Thomann-Straße 1 • 96138 Burgebrach Germany • www.thomann.de



EN