
EN

## **Features**

- To connect one guitar to multiple amps
- Prevents hum and buzz noise
- Also suitable to avoid signal loss in long cable systems
- Unbalanced 1/4" input socket
- 1/4" 'Link' output

- Isolated 1/4" output with switchable phase
- 1/4" 'LoZ' output
- Adjustable gain
- Uses 1 x 9 V (rechargeable) battery
- Connection for optional power adapter 9-15 V DC







## **Operating**

People find themselves in trouble when trying to hook up one instrument to multiple amplifiers. They get a loud hum and buzz noise. The HX3 guitar splitter has been developed to solve these kind of problems.

The special high-impedance input circuitry of the HX3 adapts your guitar signal, driving a transformer which routes the ungrounded signal to the output. Ground hum and buzz are eliminated.

HX3 also serves as a line driver for long leads and it allows for phase reversal of the output of the second amplifier. This is very convenient when you're using two amplifiers.

Setting up is easy - the HX3 has two amplifier outputs, 'Lo Z output' and 'isolated output'. Connect them directly to the instrument inputs of each amplifiers: 'Lo Z output' is directly coupled and 'isolated output' is transformer isolated. Connect an (optional) power adapter or use a battery, plug in your guitar and you are ready to go.

This device is intended to be used to distribute incoming audio signals to several device internal outputs. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

Ensure that plastic bags, packaging, etc. are properly disposed of and are not in the reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts (e.g. knobs or the like) from the product. They could swallow the pieces and choke! Never let children use electrical devices unattended.

For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

Batteries must not be disposed of as domestic waste or thrown into fire. Dispose of batteries according to national or local regulations regarding hazardous waste. To protect the environment, dispose of empty batteries at your retail store or at appropriate collection sites.

Thomann GmbH Hans-Thomann-Straße 1 • 96138 Burgebrach Germany • www.thomann.de

